

SECTION 18

INDEX

Subject	Page No.	Subject	Page No.
A			
Access Hole Covers, Tail Gate Inner Panel	9-2	Arm Rest (Center) and Curtain Assembly, Front Seat Back - Standard Full Width . .	15-22
Actuator Assembly, Folding Top - "Z" Body	13-30	Arm Rest (Center) and Curtain Assembly, Front Seat Back - Notch Down and Strato Seat Back	15-23
Actuator Assembly (Horizontal) - Power Operated Four-Way Bucket Seat Adjuster	15-38	Arm Rest (Center) and Curtain, Rear Seat . .	15-42
Actuator, Front and Rear Door Vacuum Lock	6-19	Arm Rest (Center) and Support Assembly, Front Seat Back - Standard Full Width . .	15-22
Adjuster Assembly, Front Seat (Manual) - Full Width	15-6	Arm Rest (Center) Hanger Plate and Linkage, Rear Seat Back	15-42
Adjuster Assembly, Front Seat (Power) - Full Width	15-9	Arm Rest Support (Center), Front Seat Back Notch Down and Strato Seat Back	15-25
Adjuster Electric Motor, Two-Way Seat - "C" Body Full Width	15-9	Arm Rests, Door	14-2
Adjuster Horizontal Actuator Assembly - Power Operated Four-Way Bucket Seat . .	15-38	Arm Rests, Rear Quarter	14-7
Adjuster Jackscrew - Power Operated Four-Way Bucket Seat	15-38	Assembly, Tail Gate	9-3
Adjuster Mechanism Lubrication, Front Seat	2-6	Assembly, Tail Gate Hinge	9-2
Adjuster Vertical Gearnut - Power Operated Four-Way Bucket Seat	15-38	Assembly, Tail Gate Support	9-3
Adjustments, Folding Top - "A" Styles . .	13-34	Auxiliary Sealing Strip, Front and Rear Door Bottom	6-5
Adjustments, Folding Top - "B & C" Styles	13-38	B	
Adjustments, Folding Top - "F" Styles . .	13-45	Back Curtain and Top Trim Assembly Installation	13-5
Adjustments, Folding Top - "Z" Styles . .	13-50	Back Curtain and Top Trim Assembly Removal	13-2
Adjustments, Rear Compartment Lid Torque Rod	8-3	Back Curtain Assembly - Complete	13-17
Adjustments, Rear Quarter Window - "A-27 & 77", "B-11" and "X-27" Styles	7-3	Back Filler Panel, Folding Rear Seat - Corvair	15-41
Adjustments, Side Roof Rail Weatherstrip Front and Rear Doors	6-11	Back Panel and Filler Panel, Folding Second Seat - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-56
Adjustments, Tail Gate Lock Striker	9-10	Back Trim Assembly, Folding Third Seat - Station Wagon Rear Seats	15-46
Air Outlet Duct and Finishing Panel Assembly, Shroud Side - "A, F, X & Z" and "26657"	5-2	Ball Point Ink - Stain Removal	10-5
Air Outlet Duct Assembly, Shroud Side - "B, C & E" Except 26657	5-2	Blood - Stain Removal	10-3
Air Outlet Duct Control Cable, Shroud Side - "A, F, X & Z" and 26657	5-4	Body Number Plate	1-1
Air Outlet Duct Control Cable, Shroud Side - "B, C & E" Except 26657	5-4	Body Opening Clearance Tolerances, Specified - Front and Rear Doors	6-11
Air Outlet Duct Door, Shroud - "A, F, X & Z" and 26657	5-4	Body Style Number	1-2
Air Outlet Duct Door, Shroud - "B, C & E" Except 26657	5-4	Body Ventilation - 16647, 26657, "E & F" Styles	5-1
Arm Knob, Manually Operated Seat Adjuster Control	15-4	Body Ventilation - All Except 16647, 26657, and "E and F" Styles	5-1
Arm Rest Assembly (Center), Front Seat Back - Notch Down and Strato Seat Back . .	15-23	Body Wiring Circuit Diagrams	16-53
		Bolt Lubrication, Door Lock Fork	2-2
		Bottom Auxiliary Sealing Strip, Front and Rear Door	6-5
		Bracket and Front Guide Assembly, Rear Door Window - "A-39" Styles	6-90
		Bucket Seat Adjuster Major Components, Four-Way - Power Operated	15-36

Subject	Page No.
Bucket Seat Adjusters - Manually Operated	15-35
Bucket Seat Adjusters - Power Operated	
Horizontal	15-36
Bucket Seat Assembly, Four or Two-Way	
(Power Operated)	15-27
Bucket Seat Assembly, Manually Operated	15-26
Bucket Seat Back Assembly (Right or Left)	
Standard Bucket - "F & Z" Styles	15-27
Bucket Seat Back Stop Cable, Passenger -	
Chevrolet "F & Z" Styles	15-27
Bulb Usage Chart	16-41

C

Cable, Passenger Bucket Seat Back Stop -	
Chevrolet "F & Z" Styles	15-27
Cams and Guides Lubrication on Styles with	
Upper Frames, Door Window Regulator	2-3
Cams and Guides Lubrication on Styles with-	
out Upper Frames, Door Window	
Regulator	2-4
Cams and Guides Lubrication, Rear Quarter	
Window Regulator	2-4
Cams and Guides Lubrication (Station Wagon),	
Tail Gate Window Regulator	2-5
Candy - Stain Removal	10-4
Carpets, Floor - Cleaning Procedure	10-3
Center and Side Trim Panels, Compartment	
Shelf - Cadillac "E" Styles	14-17
Center Arm Rest and Curtain Assembly,	
Front Seat Back - Notch Down and	
Strato Seat Back	15-23
Center Arm Rest and Curtain Assembly,	
Front Seat Back - Standard Full Width	15-22
Center Arm Rest and Curtain, Rear Seat	15-42
Center Arm Rest and Support Assembly,	
Front Seat Back - Standard Full Width	15-22
Center Arm Rest Assembly, Front Seat Back	
- Notch Down and Strato Seat Back	15-23
Center Arm Rest Hanger Plate and Linkage,	
Rear Seat Back	15-42
Center Arm Rest Support, Front Seat Back -	
Notch Down and Strato Seat Back	15-25
Center Finishing Panel, Compartment	
Shelf - Oldsmobile and Buick "E" Styles	14-16
Center Pillar Weatherstrips, Front and Rear	
Doors - "C-69" Styles	6-11
Channels, Lower - Tail Gate Glass Run	9-7
Checking Procedure, Electrical - Folding	
Top Hydro-Lectric System	13-25
Checking Procedure, Hydraulic - Folding	
Top Hydro-Lectric System	13-27
Checking Procedure, Mechanical - Folding	
Top Hydro-Lectric System	13-25
Chewing Gum - Stain Removal	10-4
Circuit Checking Procedures, Power	
Window	16-3
Circuit Diagrams, Body Wiring	16-53

Subject	Page No.
Clearance Tolerances, Specified Body	
Opening - Front and Rear Doors	6-11
Clips, Front and Rear Door Spring	6-11
Cloth Headlining - All Styles Except "55-65"	
Station Wagon Styles	11-11
Coated Fabrics - Cleaning Procedure	10-3
Coding, Lock Cylinder	1-3
Compartment Door, Instrument Panel - All	
Buick Styles	5-4
Compartment Door Hinge Lubrication -	
Instrument Panel	2-1
Compartment Door Locks, Instrument Panel -	
All Buick Styles	5-5
Compartment Floor Panel Assembly (At	
Kick-Up) - Station Wagon Rear Seats	15-47
Compartment Floor Panel (At Kick-Up),	
Rear - Two Seat Styles - "A" Body	
Station Wagon (Except "65" Styles)	15-51
Compartment Front Panel, Rear - 39487,	
39687 and 49487 Styles	8-3
Compartment Hinges and Torque Rod	
Lubrication, Front	2-1
Compartment Hinges Lubrication, Rear	2-7
Compartment Latch Striker, Rear Engine -	
Corvair	8-7
Compartment Lid, Front - Corvair	5-7
Compartment Lid, Rear - All Except	
Corvair	8-1
Compartment Lid, Rear Engine - Corvair	
Styles	8-1
Compartment Lid Electric Release System,	
Rear	8-11
Compartment Lid Emblem and Lock Cyl-	
inder Assembly, Rear - All Cadillac	
Styles	8-6
Compartment Lid Latch, Rear Engine - All	
Corvair Styles	8-7
Compartment Lid Lock Cylinder, Front -	
Corvair	5-8
Compartment Lid Lock Cylinder Assembly,	
Rear - All Styles Except Cadillac	8-4
Compartment Lid Lock Lubrication, Front	2-1
Compartment Lid Lock Lubrication, Rear	2-8
Compartment Lid Lock Striker, Rear	8-9
Compartment Lid Mechanical Pull-Down	
Unit, Rear - All Cadillac Styles	8-6
Compartment Lid Mechanical Pull-Down Unit	
Hydraulic Cylinder, Rear - Cadillac	8-7
Compartment Lid Lock Striker, Front -	
Corvair	5-9
Compartment Lid Support, Rear Engine -	
Corvair Styles	8-4
Compartment Lid Support Lubrication,	
Engine	2-8
Compartment Lid Torque Rod Adjustments,	
Rear	8-3
Compartment Lid Torque Rods, Front -	
Corvair	5-7
Compartment Lid Vacuum Release System,	
Rear	8-10

Subject	Page No.	Subject	Page No.
Compartment Lock - Optional 15-16000 Two-Seat Styles, Luggage - Station Wagon Rear Seats	15-50	Deluxe Seat Belt Retractor Floor Mount . . .	15-50
Compartment Lock Cylinder, Luggage (Optional - 15-16000 Two-Seat Styles) - Station Wagon Rear Seats	15-49	Detent Spring and Head Restraint Support Guide - Strato Seat Back	15-30
Compartment Pan Side Filler Panel - Station Wagon Rear Seats	15-44	Diagrams, Body Wiring Circuit	16-53
Compartment Shelf Center Finishing Panel - Oldsmobile and Buick "E" Styles	14-16	Division Channel, Rear Door Window Stationary Ventilator - "X-69" Styles . .	6-88
Compartment Shelf Side and Center Trim Panels - Cadillac "E" Style	14-17	Door Arm Rests	14-2
Compartment Shelf Side Finishing Panels - Oldsmobile and Buick "E" Styles	14-16	Door Bottom Auxiliary Sealing Strip, Front and Rear Door	6-5
Compartment Shelf Trim - All Except "E" Styles	14-15	Door Bottom Drain Hole Sealing Strips, Front and Rear Doors	6-4
Control Arm Knob, Manually Operated Seat Adjuster	15-4	Door Hinge Lubrication, Gas Tank Filler . .	2-6
Control Cable, Shroud Side Air Outlet Duct - "A, F, X & Z" and 26657	5-4	Door Hinge Lubrication, Instrument Panel Compartment	2-1
Control Cable, Shroud Side Air Outlet Duct - "B, C & E" Except 26657	5-4	Door Hinge Assembly Lubrication, Front . .	2-2
Control Valve, Fluid - Folding Top Hydro-Lectric System	11-25	Door Hinge Assembly Lubrication, Rear . .	2-2
Convertible Top Hinge Mechanism Lubrication	2-7	Door Hinges, Front - All Styles	6-48
Cover Panel and Filler Panel, Luggage Compartment - "A-55" Split Seat Option and all "65" Styles (Station Wagon)	15-58	Door Inside Handles	14-2
Cover Panel, Rear Quarter Wheelhouse - Right Side ("B" Body Station Wagons) . .	14-11	Door, Instrument Panel Compartment - All Buick Styles	5-4
Cover Panel, Spare Tire	14-13	Door Jamb Switch Lubrication	2-3
Cover Panel, Wheelhouse Trim - Right Side ("A" Body Station Wagon Styles)	14-14	Door Lock Actuator, Front and Rear Door Vacuum	6-19
Cover, Tail Gate Inner Panel	9-1	Door Lock Fork Bolt Lubrication	2-2
Covers, Access Hole - Tail Gate Inner Panel	9-2	Door Locking Mechanism and Lock Parts Lubrication	2-3
Covers, Instrument Panel - Chevrolet Styles	5-5	Door Locks, Instrument Panel Compartment - All Buick Styles	5-5
Curtain Assembly and Center Arm Rest, Front Seat Back - Standard Full Width . .	15-22	Door Outside Remote Control Mirror, Front	6-50
Curtain Assembly and Center Arm Rest, Front Seat Back - Notch Down and Strato Seat Back	15-23	Door Pull Handles	14-1
Curtain Assembly, Back - Complete	13-17	Door Removal and Installation - All Styles .	6-48
Curtain and Center Arm Rest, Rear Seat . .	15-42	Door, Shroud Air Outlet Duct - "B, C & E" Except 26657	5-4
Cushion Assembly, Rear Seat - Two Seat Styles - "A" Body Station Wagon (Except "65" Styles)	15-50	Door, Shroud Air Outlet Duct - "A, F, X & Z" and 26657	5-4
Cushion Assembly, Folding Second Seat - Right or Left Seat - "A-55" Split Seat Option and all "65" Styles (Station Wagon)	15-53	Door Trim Assemblies (Except Corvair) . .	14-3
Cushion, Rear Seat - All Styles Except "A-65"	15-39	Door Trim Assemblies (Corvair)	14-6
Cylinder Coding, Lock	1-3	Door Wedge Plates, Front Door - "67" Styles	6-69
		Door Window Regulator Lubrication, Cams and Guides on Styles with Upper Frames .	2-3
		Door Window Regulator Lubrication, Cams and Guides on Styles without Upper Frames	2-4
		Drain Hole Sealing Strips, Front and Rear Door Bottom	6-4
		Drain Hole Sealing Strips, Tail Gate	9-11
		Drive Belt and Pulleys, Transmission and Motor - Power Operated Four-Way Bucket Seat Adjusters	15-37
		Drive Cables (Horizontal and Vertical), Four-Way Seat Adjuster - Buick "B, C & E" Full Width	15-14
		Drive Cables (Vertical and Horizontal), Four-Way Seat Adjuster - "A" Body Full Width	15-12
		Drive Cables (Vertical and Horizontal), Six-Way Seat Adjuster - "B, C & E" Body Full Width	15-18
		Duct Assembly, Shroud Side Outlet - "B, C & E" Except 26657	5-2

D

Deflector, Water - Tail Gate Inner Panel . . 9-1

Subject	Page No.	Subject	Page No.
E		F	
Electric Four-Way Tilt Seat	16-28	Fabric Cover, Tail Gate	12-15
Electric Motor, Front and Rear Door Window Regulator	6-26	Fabric Roof Cover - Cleaning Procedure . .	10-3
Electric Motor, Two-Way Seat Adjuster - "C" Body Full Width	15-9	Fabric Roof Cover (All Styles Except Station Wagons)	12-1
Electric Motor, Four-Way Seat Adjuster - "A" Body Full Width	15-10	Fabric Roof Cover (Station Wagon Styles) . .	12-11
Electric Motor, Four-Way Seat Adjuster - Buick "B, C & E" Full Width	15-13	Fabric Roof Cover Installation (Styles With Pad)	12-2
Electric Motor, Six-Way Seat Adjuster - "B, C & E" Body Full Width	15-16	Fabric Roof Cover Installation (Styles Without Pad)	12-2
Electric Regulator Motor, Tail Gate Window	9-5	Filler Door Hinge Lubrication, Gas Tank . .	2-6
Electric Release System, Rear Compartment Lid	8-11	Filler Panel and Back Panel, Folding Second Seat - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-56
Electric Seats, Horizontal	16-25	Filler Panel and Cover Panel, Luggage Compartment - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-58
Electric Six-Way Tilt Seats	16-33	Filler Panel and Seat Back, Folding Rear - Corvair	15-41
Electrical Checking Procedure - Folding Top Hydro-Electric System	13-25	Filler Panel, Compartment Pan Side - Station Wagon Rear Seats	15-44
Electrical Checking Procedure - Power Window Circuit	16-3	Filler Panel, Folding Rear Seat - Corvair . .	15-41
Emblem and Lock Cylinder Assembly, Rear Compartment - All Cadillac Styles . . .	8-6	Filler Panel, Rear Floor - "A" Body Station Wagon (Except "65" Styles)	15-51
Engine Compartment Latch Striker, Rear - Corvair	8-7	Filler Panel, Rear Floor - Station Wagon Rear Seats	15-47
Engine Compartment Lid Latch, Rear - All Corvair Styles	8-7	Filler Panel (Rear Floor to Tail Gate) Assembly - 25000-26000 Styles (Station Wagon Rear Seats)	15-44
Engine Compartment Lid Support Lubrication	2-8	Finishing Panel and Air Outlet Duct Assembly Shroud Side - "A, F, X & Z" and 26657 . .	5-2
Engine Compartment Lid, Rear - Corvair Styles	8-1	Finishing Panel, Compartment Shelf Center - Oldsmobile and Buick "E" Styles	14-16
Engine Compartment Lid Support, Rear - Corvair Styles	8-4	Finishing Panel, Compartment Shelf Side - Oldsmobile and Buick "E" Styles	14-16
Exterior Moldings -		Finishing Panel, Shroud Side - "B, C & E" Except 26657	5-1
Chevrolet "A" Body Styles	17-6	Flocked Type Headlining	11-5
"B" Body Styles	17-17	Floor Carpets - Cleaning Procedure	10-3
"F" Body Styles	17-28	Floor Filler Panel, Rear - "A" Body Station Wagon (Except "65" Styles)	15-51
"X" Body Styles	17-31	Floor Filler Panel, Rear - Station Wagon Rear Seats	15-47
"Z" Body Styles	17-35	Floor Mount, Deluxe Seat Belt Retractor . .	15-50
Pontiac "A" Body Styles	17-39	Floor Mount, Standard Seat Belt Retractor .	15-50
"B" Body Styles	17-48	Floor Pan Linkage, Folding Second Seat Front - Right or Left Seat - "A-55" Split Seat Option and all "65" Styles (Station Wagon)	15-55
"F" Body Styles	17-59	Floor Pan Linkage, Folding Second Seat Rear - Right or Left Seat - "A-55" Split Seat Option and all "65" Styles (Station Wagon)	15-55
Oldsmobile "A" Body Styles	17-62	Floor Panel Assembly (At Kick-Up), Compartment - Station Wagon Rear Seats . .	15-47
"B-C" Body Styles	17-73	Floor Panel Covering, Rear Compartment - Styles with Floor Carpet - "A" body Station Wagon (Except "65" Styles)	15-50
"E" Body Styles	17-84		
Buick "A" Body Styles	17-87		
"B-C" Body Styles	17-97		
"E" Body Styles	17-106		
Cadillac "C" Body Styles	17-109		
"D" Body Styles	17-117		
"E" Body Styles	17-120		
Acadian "X" Body Styles (Canadian) . .	17-123		
Beaumont "A" Body Styles (Canadian) . .	17-126		
Pontiac "B" Body Styles (Canadian) . . .	17-132		
Exterior Molding Sealing Operation	17-1		
Exterior Molding Tools and Care	17-3		

Subject	Page No.	Subject	Page No.
Floor Panel Covering, Rear Compartment - Styles with Rubber Mat - "A" Body Station Wagon (Except "65" Styles)	15-50	Folding Second Seat Cushion Assembly - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-53
Floor Panel Covering, Rear Compartment - Styles with Vinyl Mat - "A" Body Station Wagon (Except "65" Styles)	15-50	Folding Second Seat Front Floor Pan Linkage - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Floor Panel (At Kick-Up), Rear Compartment - Two Seat Styles - "A" Body Station Wagon (Except "65" Styles)	15-51	Folding Second Seat Rear Floor Pan Linkage - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Floor Panels and Folding Rear Seats, Station Wagon - "B" Body	15-43	Folding Second Seat Side Inner Linkage - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Floor Panels and Folding Seats, Station Wagon - "A" Body (Except "65" Styles)	15-50	Folding Second Seat Side Outer Linkage - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Fluid Control Valve - Folding Top Hydro- Lectric System	13-25	Folding Second Split Seat Back Inner Linkage Assembly	15-49
Folding Rear Seats and Floor Panels, Station Wagon - "B" Body	15-43	Folding Third Seat Back Panel Assembly - Station Wagon Rear Seats	15-47
Folding Rear Seat Back and Filler Panel - Corvair	15-41	Folding Third Seat Back Panel Trim Assem- bly or Seat Back Panel Assembly - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-57
Folding Rear Seat Back and Panel Assembly - Two Seat Styles - "A" Body Station Wagon (Except "65" Styles)	15-51	Folding Third Seat Back Trim Assembly - Station Wagon Rear Seats	15-46
Folding Rear Seat Back Assembly - Corvair	15-41	Folding Third Seat Cushion - Station Wagon Rear Seats	15-46
Folding Rear Seat Back - "F" Body Styles	15-40	Folding Top - Cleaning Procedure	10-3
Folding Rear Seat Back Filler Panel - Corvair	15-41	Folding Top Adjustments - "A" Styles	13-34
Folding Rear Seat Back Linkage - Corvair	15-41	Folding Top Adjustments - "B & C" Styles	13-38
Folding Rear Seat Back Lock - Corvair	15-42	Folding Top Adjustments - "F" Styles	13-45
Folding Rear Seat Back Lock - "F" Body Styles	15-40	Folding Top Adjustments - "Z" Styles	13-50
Folding Rear Seat Back Trim and Spring Assembly - Two Seat Styles - "A" Body Station Wagon (Except "65" Styles)	15-50	Folding Top Operation - Folding Top Hydro-Lectric System	13-24
Folding Seat Linkage Lubrication	2-6	Folding Top Silencer	13-21
Folding Seats and Floor Panels, Station Wagon - "A" Body (Except "65" Styles)	15-50	Folding Top Trim Assembly - Complete	13-1
Folding Second Seat Assembly - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-52	Folding Top Trim Cover Installation	13-14
Folding Second Seat Back Trim Assembly - Station Wagon Rear Seats	15-47	Folding Top Trim Cover Removal	13-11
Folding Second Seat Back Linkage Assembly - Full Width and Split Outer Linkage - Station Wagon Rear Seats	15-49	Folding Top Trim - Less Back Curtain	13-11
Folding Second Seat Back Lock - All "A & B" Station Wagon Styles Except "55-65" Styles	15-51	Foot Rest Assembly - Cadillac "68169" Styles	15-25
Folding Second Seat Back Lock - Right or Left Seat - "A-55" Split Seat Option and all "65" Styles (Station Wagon)	15-55	Fork Bolt Lubrication, Door Lock	2-2
Folding Second Seat Back Panel and Filler Panel - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-56	Four or Two-Way Bucket Seat Assembly (Power Operated)	15-27
Folding Second Seat Back Trim, Panel and Linkage Assembly - Station Wagon Rear Seats	15-48	Four-Way Bucket Seat Adjuster Major Com- ponents (Power Operated)	15-36
Folding Second Seat Back Trim and Spring Assembly - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-54	Four-Way Seat Adjuster Electric Motor - "A" Body Full Width	15-10
		Four-Way Seat Adjuster Electric Motor - Buick "B-C & E" Full Width	15-13
		Four-Way Seat Adjuster Horizontal and Vertical Drive Cables - "A" Body Full Width	15-12
		Four-Way Seat Adjuster Horizontal and Vertical Drive Cables - Buick "B, C & E" Full Width	15-14
		Four-Way Seat Adjuster Horizontal Actuator - "A" Body Full Width	15-12

Subject	Page No.
Four-Way Seat Adjuster Horizontal Actuator - "A" Body Full Width	15-12
Four-Way Seat Adjuster Horizontal Actuator - Buick "B, C & E" Full Width	15-14
Four-Way Seat Adjuster Jackscrew - "A" Body Full Width	15-12
Four-Way Seat Adjuster Major Components - "A" Body Full Width	15-10
Four-Way Seat Adjuster Major Components - Buick "B-C & E" Full Width	15-13
Four-Way Seat Adjuster Transmission - "A" Body Full Width	15-12
Four-Way Seat Adjuster Transmission - Buick, "B, C & E" Full Width	15-14
Four-Way Seat Adjuster Vertical Gearnut - "A" Body Full Width	15-10
Four-Way Seat Adjuster Vertical Gearnut - Buick "B, C & E" Full Width	15-13
Four-Way Tilt Seat, Electric	16-28
Front and Rear Door Weatherstrips	6-2
Front and Rear Panel Assemblies, Luggage Compartment - Two Seat Styles - Station Wagon Rear Seats	15-45
Front and Rear Panel Hinge Assembly, Luggage Compartment - Two Seat Styles - Station Wagon Rear Seats	15-45
Front Seat Assembly - Full Width	15-6
Front Compartment - Corvair	5-7
Front Compartment Hinges and Torque Rod Lubrication	2-1
Front Compartment Lid - Corvair	5-7
Front Compartment Lid Gutter Weatherstrip - Corvair	5-10
Front Compartment Lid Lock Assembly - Corvair	5-9
Front Compartment Lid Lock Cylinder - Corvair	5-8
Front Compartment Lid Lock Lubrication	2-1
Front Compartment Lid Lock Striker - Corvair	5-9
Front Compartment Lid Torque Rods - Corvair	5-7
Front Compartment Hinge Assembly Lubrication	2-2
Front Door Hinges - All Styles	6-48
Front Floor Pan Linkage, Folding Second Seat - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Front Guide and Bracket Assembly, Rear Door Window - "A-39" Styles	6-90
Front Guide, Rear Quarter Window - "B-C 47-57-67 & 87" Styles	7-18
Front Guide, Rear Quarter Window - "Z" Hardtop and Convertible and "E-87" Styles	7-22
Front Panel, Rear Compartment - 39487, 39687 and 49487 Styles	8-3
Front Seat Adjuster Assembly (Manual) - Full Width	15-6

Subject	Page No.
Front Seat Adjuster Assembly (Power) - Full Width	15-9
Front Seat Adjuster Mechanism Lubrication	2-6
Front Seat Assembly - Manual - Full Width	15-6
Front Seat Assembly - Power - Full Width	15-7
Front Seat Back Assembly - Four Door Style - Standard Full Width	15-19
Front Seat Back Assembly (Right or Left) - Two Door Style Standard Seat	15-20
Front Seat Back Assembly (Right or Left) - "A-39" Style - Full Width and Center Arm Rest	15-20
Front Seat Back Center Arm Rest and Curtain Assembly - Notch Down and Strato Seat Back	15-23
Front Seat Back Center Arm Rest and Curtain Assembly - Standard Full Width	15-22
Front Seat Back Center Arm Rest and Support Assembly - Standard Full Width	15-22
Front Seat Back Center Arm Rest Assembly - Notch Down and Strato Seat Back	15-23
Front Seat Back Center Arm Rest Support - Notch Down and Strato Seat Back	15-25
Front Seat Back Head Restraint - Full Width	15-22
Front Seat Back Lock - Standard Full Width - "A, B, X and Z"	15-20
Front Seat Back Lock - Standard Full Width - "C & E" Body	15-21
Front Seat Back, Reclining	15-32
Front Seat Back Head Restraint Support - Full Width	15-22
Front Seats, Strato	15-26
Front Trim Panel, Rear Quarter - Right or Left ("A" Body Station Wagon Styles)	14-14
Front Vertical Gearnut, Six-Way Seat Ad- juster - "B, C & E" Body Full Width	15-16
Fruit, Fruit stains, Liquor and Wine - Stain Removal	10-4

G

Gas Tank Filler Door Hinge Lubrication	2-6
Gearnut Assembly (Horizontal), Two-Way Seat Adjuster - "C" Body Full Width	15-9
Gearnut (Vertical), Four-Way Seat Adjuster - "A" Body Full Width	15-10
Gearnut (Vertical), Four-Way Seat Adjuster - Buick "B, C & E" Full Width	15-13
Gearnut (Front Vertical), Six-Way Seat Ad- juster - "B, C & E" Full Width	15-16
Gearnut (Rear Vertical), Six-Way Seat Ad- juster - "B, C & E" Body Full Width	15-17
Gearnut (Vertical) - Power Operated Four- Way Bucket Seat Adjuster	15-38
Genuine Leather - Cleaning Procedure	10-3
Glass Installation, Stationary (Extended Method)	4-4

Subject	Page No.	Subject	Page No.
Glass Installation, Stationary (Short Method)	4-3	Head Restraint, Strato Seat	15-30
Glass Polishing	1-6	Head Restraint Support Guide and Detent Spring, Strato Seat Back	15-30
Glass Removal - Stationary	4-2	Hinge and Torque Rod Lubrication, Front Compartment	2-1
Glass Run Channel, Front Door Window - "A & X" Closed Styles	6-67	Hinge Assembly, Luggage Compartment Rear and Front Panel - Two Seat Styles - Station Wagon Rear Seats	15-45
Glass Run Channel, Front Door Window - "B" Closed Styles	6-68	Hinge Assembly, Tail Gate	9-2
Glass Run Channel, Front - Rear Quarter Window - All Closed Styles	7-4	Hinge, Front Door - All Styles	6-48
Glass Run Channel, Inner and Outer Strip Assemblies, Front and Rear Door	6-6	Hinge, Rear Doors - All Styles	6-82
Glass Run Channel, Rear - Rear Quarter Window - All Closed Styles	7-3	Hinge Assembly Lubrication - Front Door	2-2
Glass Run Channel, Rear Door Window - All Styles	6-91	Hinge Assembly Lubrication - Rear Door	2-2
Glass Run Channel, Rear Door Window - All "A & X" Closed Styles	6-91	Hinge Lubrication, Gas Tank Filler Door	2-6
Glass Run Channel, Rear Quarter Window - "E-47" Styles	7-24	Hinge Lubrication, Instrument Panel Compartment Door	2-1
Glass Run Channels, Lower - Tail Gate	9-7	Hinge Lubrication, Rear Compartment	2-7
Glass Run Channels, Tail Gate Upper	9-12	Hinge Lubrication (Station Wagon), Tail Gate	2-5
Glass Waterleak Correction - Stationary	4-6	Hinge Mechanism Lubrication, Convertible Top	2-7
Grease and Oil - Stain Removal	10-4	Hole Covers, Access - Tail Gate Inner Panel	9-2
Guide Assembly, Rear Quarter - "F" Styles	7-24	Horizontal Actuator Assembly - Power Operated Four-Way Bucket Seat Adjuster	15-38
Guide Assembly, Rear Quarter Window - "A" Hardtop and Convertible Styles	7-24	Horizontal Actuator, Four-Way Seat Adjuster - "A" Body Full Width	15-12
Guide and Cams Lubrication on Styles with Upper Frame, Door Window Regulator	2-3	Horizontal Actuator, Four-Way Seat Adjuster - Buick "B, C & E" Full Width	15-14
Guide and Cams Lubrication on Styles without Upper Frames, Door Window Regulator	2-4	Horizontal Actuator, Six-Way Seat Adjuster - "B, C & E" Body Full Width	15-16
Guides and Cams Lubrication, Rear Quarter Window Regulator	2-4	Horizontal and Vertical Drive Cables, Four-Way Seat Adjuster - "A" Body Full Width	15-12
Guides and Cams Lubrication (Station Wagon), Tail Gate Window Regulator	2-5	Horizontal and Vertical Drive Cables, Four-Way Seat Adjuster - Buick "B, C & E" Full Width	15-14
Gutter Weatherstrip, Front Compartment Lid - Corvair	5-10	Horizontal and Vertical Drive Cables, Six-Way Seat Adjuster - "B, C & E" Body Full Width	15-18
H		Horizontal and Vertical Drive Cable, Transmission Assembly - Power Operated Four-Way Bucket Seat Adjuster	15-38
Handle, Door Inside	14-2	Horizontal Bucket Seat Adjuster - Power Operated	15-36
Handle, Door Pull	14-1	Horizontal Gearnut Assembly, Two-Way Seat Adjuster - "C" Body Full Width	15-9
Handle, Outside - Tail Gate Window Regulator (Manual or Electric)	9-6	Horizontal Jackscrew, Two-Way Seat Adjuster - "C" Body Full Width	15-10
Handle, Outside - Front And Rear Doors	6-11	Horizontal Seats, Electric	16-25
Hanger Plate and Linkage (Center Arm Rest), Rear Seat Back	15-42	Hydraulic Checking Procedure - Folding Top Hydro-Lectric System	13-27
Headlining - Cloth and Vinyl Coated (Soft) - All Styles Except "55-65" Station Wagon Styles	11-11	Hydraulic Cylinder, Rear Compartment Lid Mechanical Pull-Down Unit - Cadillac	8-7
Headlining - Flocked Type	11-5	Hydro-Lectric System - Folding Top	13-22
Headlining - Vinyl - One-Peice Formed (Hard)	11-9		
Headlining - "55-65" Station Wagons	11-5		
Head Restraint, Front Seat Back - Full Width	15-22		

Subject	Page No.	Subject	Page No.
I			
Ice Cream - Stain Removal	10-4	Lid Latch, Rear Engine Compartment - All Corvair Styles	8-7
Identification, Model	1-2	Lid Lock Assembly, Front Compartment - Corvair	5-9
Identification Number, Vehicle	1-3	Lid Lock Cylinder, Front Compartment - Corvair	5-8
Ink, Ball Point - Stain Removal	10-5	Lid Lock Cylinder Assembly, Rear Com- partment - All Styles Except Cadillac . .	8-4
Inner and Outer Strip Assemblies, Front and Rear Door Glass Run Channel	6-6	Lid Lock Lubrication, Front Compartment	2-1
Inner and Outer Strip Assemblies, Tail Gate Window	9-11	Lid Lock Lubrication, Rear Compartment .	2-8
Inner Linkage Assembly, Folding Second Split Seat Back	15-49	Lid Lock Striker, Front Compartment - Corvair	5-9
Inner Panel Access Hole Covers, Tail Gate	9-2	Lid Lock Striker, Rear Compartment . . .	8-9
Inner Panel Cam, Front Door	6-50	Lid, Rear Compartment - All Except Corvair	8-1
Inner Panel Cam, Rear Door - All Except "A & X-69" Styles	6-88	Lid, Rear Engine Compartment - Corvair Styles	8-1
Inner Panel Cover, Tail Gate	9-1	Lid Support, Rear Engine Compartment - Corvair Styles	8-4
Inner Panel Sealing, Rear Quarter	7-1	Lid Support Lubrication, Engine Compartment	2-8
Inner Panel Water Deflector, Front and Rear Door	6-5	Lid Torque Rod Adjustments, Rear Compartment	8-3
Inner Panel Water Deflector, Tail Gate . .	9-1	Lid Vacuum Release System, Rear Compartment	8-10
Inner Sealing Strip Assembly, Vertical - Rear Quarter - "C-47" Styles	7-5	Lift Assembly, Manual - Manually Op- erated Folding Top	13-33
Inside Handle, Door	14-2	Linkage and Hanger Plate (Center Arm Rest), Rear Seat Back	15-42
Inside Handle, Remote Control - Tail Gate "B" Styles	9-7	Linkage Assembly, Folding Seat Back - Full Width and Split Outer Linkage - Station Wagon Rear Seats	15-49
Installation of Top and Back Curtain Trim Assembly	13-5	Linkage Assembly (Inner), Folding Second Split Seat Back	15-49
Instrument Panel Compartment Door - All Buick Styles	5-4	Linkage, Folding Seat Back - Corvair . .	15-41
Instrument Panel Compartment Door Hinge Lubrication	2-1	Linkage, Folding Second Seat Side Inner - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Instrument Panel Compartment Door Locks - Buick All Styles	5-5	Linkage, Folding Second Seat Side Outer - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Instrument Panel Covers - Chevrolet Styles	5-5	Linkage Lubrication, Folding Seat	2-6
J			
Jackscrew, Four-Way Seat Adjuster - "A" Body Full Width	15-12	Linkage, Panel and Trim Assembly, Folding Second Seat Back Trim - Station Wagon Rear Seats	15-48
Jackscrew (Horizontal), Two-Way Seat Adjuster - "C" Body Full Width	15-10	Lipstick - Stain Removal	10-5
Jackscrew - Power Operated Four-Way Bucket Seat Adjuster	15-38	Liquor, Wine, Fruit, Fruit Stains - Stain Removal	10-4
Jamb Switch (Electric), Tail Gate	9-7	Lock Actuator, Front and Rear Door Vacuum	6-19
Jamb Switch Lubrication, Door	2-3	Lock Assembly, Front Compartment Lid - Corvair	5-9
L			
Lamps - Tail and Side Marker	16-40	Lock Assembly, Front Door - All Styles .	6-51
Latch Striker, Rear Engine Compartment - Corvair	8-7	Lock Assembly, Rear Door - All Styles .	6-83
Lid Electric Release System, Rear Compartment	8-11	Lock Assembly, Tail Gate	9-9
Lid Gutter Weatherstrip, Front Compart- ment - Corvair	5-10	Lock Control Assembly, Reclining Seat Back	15-35
		Lock Control, Lock Rod and Seat Back Lock, Strato - All Two-Door Except Reclining Strato	15-31

Subject	Page No.	Subject	Page No.
Lock Control Support, Reclining Seat Back . . .	15-33	Lock Striker, Front Compartment Lid -	
Lock Cylinder and Emblem Assembly,		Corvair	5-9
Rear Compartment - All Cadillac Styles . .	8-6	Lock Striker, Rear Compartment Lid . . .	8-9
Lock Cylinder Assembly, Front Door -		Lock Striker Lubrication (Station Wagon),	
All Styles	6-51	Tail Gate	2-4
Lock Cylinder Assembly, Rear Compartment		Lock System, Front and Rear Door	
Lid - All Styles Except Cadillac . .	8-4	Vacuum	6-19
Lock Cylinder Coding	1-3	Lock Trouble Diagnosis Procedure, Front	
Lock Cylinder, Front Compartment Lid -		and Rear Door Vacuum	6-21
Corvair	5-8	Lower and Upper Channel and Plastic	
Lock Cylinder (Optional - 15-16000 Two		Slides, Six-Way Seat Adjuster - "B, C &	
Seat Styles), Luggage Compartment -		E" Body Full Width	15-17
Station Wagon Rear Seats	15-49	Lower Glass Run Channels, Tail Gate . . .	9-7
Lock, Folding Rear Seat Back - "F"		Lower Trim, Rear Quarter ("A-80" Style	
Body Styles	15-40	and All 4-Door Styles Except Station	
Lock, Folding Rear Seat Back - Corvair . .	15-42	Wagon)	14-10
Lock, Folding Second Seat Back - All		Luggage Compartment Cover Panel and	
"A" & "B" Station Wagon Styles		Filler Panel - "A-55" Split Seat Option	
Except "55-65" Styles	15-51	and All "65" Styles (Station Wagon) . . .	15-58
Lock, Folding Second Seat Back - Right		Luggage Compartment Front and Rear	
or Left Seat "A-55" Split Seat Option		Panel Assemblies - Two Seat Styles -	
and All "65" Styles (Station Wagon) . . .	15-55	Station Wagon Rear Seats	15-45
Lock Fork Bolt Lubrication, Door	2-22	Luggage Compartment Front and Rear	
Lock, Front Seat Back - Standard Full		Panel Hinge Assembly - Two Seat	
Width - "C & E" Body	15-21	Styles - Station Wagon Rear Seats	15-45
Lock, Front Seat Back - Standard Full		Luggage Compartment Lock - Optional	
Width - "A, B, X & Z" Body	15-20	15-16000 Two-Seat Styles - Station	
Lock, Instrument Panel Compartment		Wagon Rear Seats	15-50
Door - All Buick Styles	5-5	Luggage Compartment Lock Cylinder (Op-	
Lock Lubrication, Front Compartment		tional - 15-16000 Two-Seat Styles) -	
Lid	2-1	Station Wagon Rear Seats	15-49
Lock Lubrication, Rear Compartment Lid .	2-8	Luggage Compartment Rear Panel Assem-	
Lock - Optional 15-16000 Two Seat Styles,		bly - Two Seat Styles - Station Wagon	
Luggage Compartment Station Wagon		Rear Seats	15-45
Rear Seats	15-50		
Locking Mechanism and Lock Parts			
Lubrication, Door	2-3		
Lock Parts and Lock Mechanism			
Lubrication, Door	2-3		
Lock Remote Control Assembly, Front			
and Rear Door Vacuum	6-21		
Lock Remote Control Assembly, Tail			
Gate	9-8		
Lock Remote Control, Front Door - All			
Styles	6-50		
Lock Remote Control, Rear Door - All			
Styles	6-82		
Lock Rod, Lock Control and Seat Back			
Lock, Strato - All Two-Door Except			
Reclining Strato	15-31		
Lock Selector Valves, Front and Rear			
Door Vacuum	6-19		
Lock Storage Tank, Front and Rear Door			
Vacuum	6-21		
Lock Striker Adjustments, Tail Gate	9-10		
Lock Striker Assembly, Tail Gate	9-9		
Lock Striker and Seat Back Lock,			
Reclining Seat Back	15-33		
Lock Striker, Front and Rear Door - All			
Styles	6-11		

M

Major Components, Two-Way Seat Ad-	
juster - "C" Body Full Width	15-9
Major Components, Four-Way Bucket Seat	
Adjuster - Power Operated	15-36
Major Components, Four-Way Seat Ad-	
juster - "A" Body Full Width	15-10
Major Components, Four-Way Seat Ad-	
juster - Buick "B-C & E" Full Width . .	15-13
Major Components, Six-Way Seat Ad-	
juster - "B, C & E" Body Full Width . .	15-15
Manual Lift Assembly - Manually Op-	
erated Folding Top	13-33
Manually Operated Bucket Seat Adjusters .	15-35
Manually Operated Bucket Seat Assembly .	15-26
Manually Operated Seat Adjuster Control	
Arm Knob	15-4
Mechanical Checking Procedure - Folding	
Top Hydro-Lectric System	13-25
Mechanical Pull-Down Unit, Rear Compartment	
Lid - All Cadillac Styles	8-6
Mechanical Pull-Down Unit Cable, Rear	
Compartment Lid - All Cadillac Styles . .	8-6

Subject	Page No.
Mechanical Pull-Down Unit Hydraulic Cylinder, Rear Compartment Lid - Cadillac	8-7
Mechanism Lubrication, Convertible Top Hinge	2-7
Mechanism Lubrication, Front Seat Adjuster	2-6
Mirror, Front Door Outside Remote Control	6-50
Model Identification	1-2
Moldings, Exterior -	
Chevrolet "A" Body	17-6
"B" Body	17-17
"F" Body	17-28
"X" Body	17-31
"Z" Body	17-35
Pontiac "A" Body	17-39
"B" Body	17-48
"F" Body	17-59
Oldsmobile "A" Body	17-62
"B-C" Body	17-73
"E" Body	17-84
Buick "A" Body	17-87
"B-C" Body	17-97
"E" Body	17-106
Cadillac "C" Body	17-109
"D" Body	17-117
"E" Body	17-120
Acadian "X" Body (Canadian)	17-123
Beaumont "A" Body (Canadian)	17-126
Pontiac "B" Body (Canadian)	17-132
Molding Sealing Operation, Exterior	17-1
Motor and Pump Assembly, Folding Top Hydro-Lectric System	13-22
Motor and Transmission Drive Belt and Pulleys - Power Operated Four-Way Bucket Seat Adjuster	15-36
Motor Assembly - Power Operated Four-Way Bucket Seat Adjuster	15-37
Motor, Electric - Tail Gate Window Regulator	9-5

N

Nausea, Stain Removal	10-4
Number Plate, Body	1-1

O

Oil and Grease - Stain Removal	10-4
Opening Weatherstrips, Tail Gate	9-11
Outer and Inner Strip Assemblies, Tail Gate Window	9-11
Outer Linkage, Folding Second Seat Side - Right or Left Side - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55

Subject	Page No.
Outer Strip Assemblies, Rear Quarter Window - All Closed Styles	7-4
Outlet Duct Assembly, Shroud Side - "B, C & E" Except 26657	5-2
Outside Handle, Front and Rear Doors	6-11
Outside Handle, Tail Gate Window Regulator (Manual or Electric)	9-6
Outside Remote Control Mirror, Front Door	6-50

P

Panel Assembly, Folding Third Seat Back - Station Wagon Rear Seats	15-47
Panel, Linkage and Trim Assembly, Folding Second Seat Back Trim - Station Wagon Rear Seats	15-48
Panel Sealing, Rear Quarter Inner	7-1
Panel Trim Assembly or Seat Back Panel Assembly, Folding Third Seat Back - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-57
Passenger Bucket Seat Back Stop Cable - Chevrolet "F & Z" Styles	15-27
Plastic Slides and Lower and Upper Channel, Six-Way Seat Adjuster - "B, C & E" Body Full Width	15-17
Plastic Slides, Two-Way Seat Adjuster - "C" Body Full Width	15-10
Plate, Body Number	1-1
Polishing, Glass	1-6
Positioning Unit, Front Reclining Seat Back	15-33
Power Operated Four-Way Bucket Seat Adjuster Major Components	15-36
Power Operated Horizontal Bucket Seat Adjuster	15-36
Power Operated Tail Gate Window	16-20
Power Operated Two or Four-Way Bucket Seat Assembly	15-27
Power Operated Windows	16-2
Power Operated Ventilators	16-17
Power Window Circuit Checking Procedures	16-3
Pull Down Unit, Rear Compartment Lid Mechanical - All Cadillac Styles	8-6
Pull Down Unit Cable, Rear Compartment Lid Mechanical - All Cadillac Styles	8-6
Pull Down Unit Hydraulic Cylinder, Rear Compartment Lid Mechanical, Cadillac	8-7
Pull Handles, Door	14-1
Pulleys and Drive Belt, Transmission and Motor - Power Operated Four-Way Bucket Seat Adjusters	15-37
Pump Assembly Operation - Folding Top Hydro-Lectric System	13-24
Pump and Motor Assembly, Folding Top Hydro-Lectric System	13-22

Subject	Page No.	Subject	Page No.
Q			
Quarter Arm Rests, Rear	14-7	Rear Compartment Weatherstrip	8-11
Quarter Lower Trim, Rear ("A-80" Style and All 4-Door Styles Except Station Wagon)	14-10	Rear Compartment Hinges Lubrication . . .	2-7
Quarter Trim, Rear	14-7	Rear Compartment Lid Lock Lubrication . .	2-8
Quarter Trim Assembly, Rear (2-Door Styles)	14-8	Rear Door Hinges - All Styles	6-82
Quarter Trim Panel, Rear - Left Side ("B" Body Station Wagons)	14-10	Rear Door Hinge Assembly Lubrication . .	2-2
Quarter Wheelhouse Cover Panel, Rear - Right Side ("B" Body Station Wagons) . .	14-11	Rear Engine Compartment Latch Striker - Corvair	8-7
Quarter Window Regulator Handle, Rear . .	14-7	Rear Engine Compartment Lid - Corvair Styles	8-1
Quarter Window Regulator Lubrication, Cams and Guides, Rear	2-4	Rear Engine Compartment Lid Latch - All Corvair Styles	8-7
R			
Rear and Front Door Weatherstrips	6-2	Rear Engine Compartment Lid Support - Corvair Styles	8-4
Rear and Front Panel Hinge Assembly, Luggage Compartment - Two Seat Styles - Station Wagon Rear Seats	15-45	Rear Floor Filler Panel - "A" Body Station Wagon (Except "65" Styles) . . .	15-51
Rear Compartment Floor Panel (At Kick- Up) - Two Seat Styles - "A" Body Station Wagon (Except "65" Styles) . . .	15-51	Rear Floor Filler Panel - Station Wagon Rear Seats	15-47
Rear Compartment Floor Panel Covering - Styles with Floor Carpet - "A" Body Station Wagon (Except "65" Styles) . . .	15-50	Rear Floor Pan Linkage, Folding Second Seat - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Rear Compartment Floor Panel Covering - Styles with Rubber Mat - "A" Body Station Wagon (Except "65" Styles) . . .	15-50	Rear Floor to Tail Gate Filler Panel Assembly - 25000-26000 Series (Station Wagon Rear Seat)	15-44
Rear Compartment Floor Panel Covering - Styles with Vinyl Mat - "A" Body Station Wagon (Except "65" Styles) . . .	15-50	Rear Guide, Rear Door Window - "A-39" Styles	6-90
Rear Compartment Front Panel - 39487, 39687 and 49487 Styles	8-3	Rear Guide, Rear Quarter Window - "Z" Hardtop and Convertible and "E-87" Styles	7-22
Rear Compartment Lid - All Except Corvair	8-1	Rear Panel Assembly, Luggage Compartment - Two Seat Styles (Station Wagon Rear Seats	15-45
Rear Compartment Lid Electric Release System	8-11	Rear Quarter Arm Rests	14-7
Rear Compartment Lid Emblem and Lock Cylinder Assembly - All Cadillac Styles	8-6	Rear Quarter Front Trim Panel - Right or Left ("A" Body Station Wagon Styles)	14-14
Rear Compartment Lid Lock Cylinder Assembly - All Styles Except Cadillac . .	8-4	Rear Quarter Inner Panel Sealing	7-1
Rear Compartment Lid Lock Striker . . .	8-9	Rear Quarter Lower Trim ("A-80" Style and All 4-Door Styles Except Station Wagon)	14-10
Rear Compartment Lid Mechanical Pull- Down Unit - All Cadillac Styles	8-6	Rear Quarter Rear Trim Panel - Left Side ("A" Body Station Wagon Styles) . .	14-14
Rear Compartment Lid Mechanical Pull- Down Unit Cable - All Cadillac Styles . .	8-6	Rear Quarter Trim	14-7
Rear Compartment Lid Mechanical Pull- Down Unit Hydraulic Cylinder - Cadillac	8-7	Rear Quarter Trim Assembly (2-Door Styles)	14-8
Rear Compartment Lid Torque Rod Adjustments	8-3	Rear Quarter Trim Panel - Left Side ("B" Body Station Wagons)	14-10
Rear Compartment Lid Vacuum Release System	8-10	Rear Quarter Wheelhouse Cover Panel - Right Side ("B" Body Station Wagons) . .	14-11
		Rear Quarter Window Adjustments - "A-27 & 77", "B-11" and "X-27" Styles	7-3
		Rear Quarter Window Assembly - All Hardtop Styles (Except "B-c" Styles) . .	7-5
		Rear Quarter Window Assembly - "A-27 & 77," "B-11 & X-27" Styles	7-2
		Rear Quarter Window Assembly - "A-37, 67 & 87" Styles	7-5
		Rear Quarter Window Assembly - "B & C 47, 57, 67 & 87" Styles	7-12

Subject	Page No.	Subject	Page No.
Rear Quarter Window Assembly - "E-47"		Rear Seat Back Lock, Folding - Corvair	15-42
Styles	7-9	Rear Seat Back Lock, Folding - "F"	
Rear Quarter Window Assembly - "E-87"		Body Styles	15-40
Styles	7-8	Rear Seats and Floor Panels, Station	
Rear Quarter Window Assembly - "F-37		Wagon Folding - "B" Body	15-43
& 67" Styles	7-7	Rear Seat Cushion - All Styles Except	
Rear Quarter Window Assembly - "Z-37		"A-65"	15-39
& 67" Styles	7-12	Rear Seat Cushion Assembly - Two Seat	
Rear Quarter Window Front Glass Run		Styles - "A" Body Station Wagon	
Channel - All Closed Styles	7-4	(Except "65" Styles)	15-50
Rear Quarter Window Front Guide - "B		Rear Trim Panel, Rear Quarter - Left	
& C 47-57-67 & 87" Styles	7-18	Side ("A" Body Station Wagon Styles) .	14-14
Rear Quarter Window Front Guide - "Z"		Rear Vertical Gearnut, Six-Way Seat	
Hardtop and Convertible and "E-87"		Adjuster - "B, C & E" Body Full	
Styles	7-22	Width	15-17
Rear Quarter Window Glass Run Channel -		Reclining Front Seat Back	15-32
"E-47" Styles	7-24	Reclining Seat Back Lock Control	
Rear Quarter Window Guide Assembly -		Assembly	15-35
"A" Hardtop and Convertible Styles . .	7-24	Reclining Seat Back Lock Control	
Rear Quarter Window Guide Assembly -		Support	15-33
"F" Styles	7-24	Reclining Seat Back Lock Striker and	
Rear Quarter Window Outer Strip		Seat Back Lock	15-33
Assemblies - All Closed Styles	7-4	Reclining Seat Back Positioning Unit,	
Rear Quarter Window Rear Glass Run		Front	15-33
Channel - All Closed Styles	7-3	Regulator Cams and Guides Lubrication,	
Rear Quarter Window Rear Guide - "Z"		Rear Quarter Window	2-4
Hardtop and Convertible and "E-87"		Regulator, Electric - "A, B & C" Hard-	
Styles	7-22	top and Convertible Front Door Window	
Rear Quarter Window Regulator (Manual		Styles	6-65
and Electric) - "A, E, F, & Z" Hard-		Regulator, Electric - "A & B" Closed	
top and Convertible Styles	7-16	Style Front Door Window	6-65
Rear Quarter Window Regulator (Manual		Regulator Handle, Rear Quarter Window .	14-7
and Electric) - "A, B & X" Closed		Regulator Lubrication, Cams and Guides	
Styles	7-17	on Styles with Upper Frames, Door	
Rear Quarter Window Regulator (Manual		Window	2-3
and Electric) - "B & C - 47, 57, 67 &		Regulator Lubrication, Cams and Guides	
87" Styles	7-15	on Styles without Upper Frames, Door	
Rear Quarter Window Regulator Handle .	14-7	Window	2-4
Rear Quarter Window Regulator Lubrication		Regulator Lubrication, Cams and Guides	
- Cams and Guides	2-4	(Station Wagon), Tail Gate Window	2-5
Rear Quarter Window Vertical Inner		Regulator Manual - "A, B & X" Closed	
Sealing Strip Assembly - "C-47"		Style Front Door Window	6-64
Styles	7-5	Regulator, Manual and Electric - 16647,	
Rear Seat Back and Filler Panel, Folding		26657 and "F" Front Door Window	
- Corvair	15-41	Style	6-66
Rear Seat Back and Panel Assembly,		Regulator, Manual and Electric - Front	
Folding - Two Seat Styles - "A" Body		Door Window "E" Styles	6-66
Station Wagon (Except "65" Styles) . .	15-51	Regulator, Manual - Front Door Window	
Rear Seat Back Assembly - All Styles		"Z" Styles	6-66
Except "F and Z" with Folding Rear		Regulator Motor, Electric - Tail Gate	
Seat Back	15-39	Window	9-5
Rear Seat Back Assembly, Folding -		Regulator Outside Handle, Tail Gate	
Corvair	15-41	Window (Manual or Electric)	9-6
Rear Seat Back Center Arm Rest and		Regulator, Rear Door Window - Manual	
Curtain	15-42	and Electric - All "A, B & C" Styles .	6-89
Rear Seat Back Center Arm Rest Hanger		Regulator, Rear Door Window - "X-69"	
Plate and Linkage	15-42	Styles	6-90
Rear Seat Back Filler Panel, Folding -		Regulator, Rear Quarter Window (Manual	
Corvair	15-41	and Electric) - "A, B & X" Closed	
Rear Seat Back Linkage, Folding - Corvair	15-41	Styles	7-17

Subject	Page No.	Subject	Page No.
Regulator, Rear Quarter Window (Manual and Electric) - "A, E, F & Z" Hard-top and Convertible Styles	7-16	Seat Adjuster Assembly, Front (Power) - Full Width	15-9
Regulator, Rear Quarter Window (Manual and Electric) - "B & C" - 47, 57, 67 & 87" Styles	7-15	Seat Adjuster, Bucket - Manually Operated	15-35
Regulator, Tail Gate Window (Manual or Electric)	9-4	Seat Adjuster Control Arm Knob, Manually Operated	15-4
Release System, Electric - Rear Compartment Lid	8-11	Seat Adjuster Electric Motor, Two-Way - "C" Body Full Width	15-9
Release System, Vacuum - Rear Compartment Lid	8-10	Seat Adjuster Electric Motor, Four-Way - "A" Body Full Width	15-10
Remote Control Assembly, Front and Rear Door Vacuum Lock	6-21	Seat Adjuster Electric Motor, Four-Way - Buick "B, C & E" Full Width	15-13
Remote Control Assembly, Tail Gate Lock	9-8	Seat Adjuster Electric Motor, Six-Way - "B, C & E" Body Full Width	15-16
Remote Control, Front Door Lock - All Styles	6-50	Seat Adjuster Front Vertical Gearnut, Six-Way - "B, C & E" Body Full Width	15-16
Remote Control Inside Handle, Tail Gate - "B" Styles	9-7	Seat Adjuster Horizontal Actuator, Four-Way - "A" Body Full Width	15-12
Remote Control Mirror, Front Door Outside	6-50	Seat Adjuster Horizontal Actuator, Four-Way - Buick "B, C & E" Full Width	15-14
Remote Control, Rear Door Lock - All Styles	6-82	Seat Adjuster Horizontal Actuator, Six-Way - "B, C & E" Body Full Width	15-16
Removal of Top and Back Curtain Trim Assembly	13-2	Seat Adjuster Horizontal and Vertical Drive Cables, Four-Way - "A" Body Full Width	15-12
Reservoir Tube, Folding Top Hydro-Lectric System	13-24	Seat Adjuster Horizontal and Vertical Drive Cables, Four-Way - Buick "B, C & E" Full Width	15-14
Restraint, Head Support, Front Seat Back - Full Width	15-22	Seat Adjuster Horizontal and Vertical Drive Cables, Six-Way - "B, C & E" Body Full Width	15-18
Retractor Floor Mount, Deluxe Seat Belt	15-50	Seat Adjuster Horizontal Gearnut Assembly, Two-Way - "C" Body Full Width	15-9
Retractor Floor Mount, Standard Seat Belt	15-50	Seat Adjuster Horizontal Jackscrew, Two-Way - "C" Body Full Width	15-10
Roof Cover, Fabric - Cleaning Procedure	10-3	Seat Adjuster Jackscrew, Four-Way - "A" Body Full Width	15-12
Roof Cover, Fabric (All Styles Except Station Wagon)	12-1	Seat Adjuster Lower and Upper Channel and Plastic Slides, Six-Way - "B, C & E" Body Full Width	15-17
Roof Cover, Fabric (Station Wagon Styles)	12-11	Seat Adjuster Major Components, Two-Way - "C" Body Full Width	15-9
Roof Cover Installation, Fabric (Styles with Pad)	12-2	Seat Adjuster Major Components, Four-Way - "A" Body Full Width	15-10
Roof Cover Installation, Fabric (Styles without Pad)	12-2	Seat Adjuster Major Components, Four-Way - Buick "B-C & E" Full Width	15-13
Roof Rail Weatherstrip and Retainer - Front and Rear Doors, Side	6-7	Seat Adjuster Major Components, Four-Way Bucket - Power Operated	15-36
Run Channel, Front Glass - Rear Quarter Window - All Closed Styles	7-4	Seat Adjuster Major Components, Six-Way - "B, C & E" Body Full Width	15-15
Run Channel, Inner and Outer Strip Assemblies, Front and Rear Door Glass	6-6	Seat Adjuster Mechanism Lubrication, Front	2-6
Run Channels, Lower - Tail Gate Glass	9-7	Seat Adjuster Plastic Slides, Two-Way - "C" Body Full Width	15-10
Run Channel, Rear Glass - Rear Quarter Window - All Closed Styles	7-3	Seat Adjuster - Power Operated Horizontal Bucket	15-36
Run Channel, Rear Quarter Window, Glass - "E-47" Styles	7-24	Seat Adjuster Rear Vertical Gearnut, Six-Way - "B, C & E" Body Full Width	15-17
Run Channel, Tail Gate Upper Glass	9-12	Seat Adjuster Transmission, Four-Way - "A" Body Full Width	15-12
S			
Seat Adjuster Assembly, Front (Manual) - Full Width	15-6		

Subject	Page No.	Subject	Page No.
Seat Adjuster Transmission, Four-Way -		Seat Back Center Arm Rest Hanger	
Buick "B, C & E" Full Width	15-14	Plate and Linkage, Rear	15-42
Seat Adjuster Transmission, Six-Way -		Seat Back Center Arm Rest Support,	
"B, C & E" Body Full Width	15-18	Front - Notch Down and Strato Seat Back .	15-25
Seat Adjuster Vertical Gearnut, Four-Way		Seat Back Filler Panel, Folding Rear -	
- "A" Body Full Width	15-10	Corvair	15-41
Seat Adjuster Vertical Gearnut, Four-Way		Seat Back, Folding Rear - "F" Body	
- Buick "B, C & E" Full Width	15-13	Styles	15-40
Seat Assembly, Folding Second - Right or		Seat Back, Front Reclining	15-32
Left Seat - "A-55" Split Seat Option		Seat Back Head Restraint, Front - Full	
and All "65" Styles (Station Wagon) . . .	15-52	Width	15-22
Seat Assembly (Bucket), Four or Two-		Seat Back Head Restraint, Strato	15-30
Way (Power Operated)	15-27	Seat Back Head Restraint Support Guide	
Seat Assembly, Front (Manual) Full		and Detent Spring, Strato	15-30
Width	15-6	Seat Back Inner Linkage Assembly, Folding	
Seat Assembly, Front (Power) - Full		Second Split	15-49
Width	15-7	Seat Back Linkage Assembly, Folding -	
Seat Assembly (Bucket), Manually		Full Width and Split Outer Linkage -	
Operated	15-26	Station Wagon Rear Seats	15-49
Seat Assembly, Strato Full Width	15-26	Seat Back Linkage, Folding Rear - Corvair	15-41
Seat Back and Filler Panel, Folding		Seat Back Lock Control Assembly,	
Rear - Corvair	15-41	Reclining	15-35
Seat Back and Panel Assembly, Folding		Seat Back Lock Control Support,	
Rear - Two Seat Styles - "A" Body		Reclining	15-33
Station Wagon (Except "65" Styles) . . .	15-51	Seat Back Lock, Folding Rear - Corvair	15-42
Seat Back Assembly, Folding Rear -		Seat Back Lock, Folding Rear - "F"	
Corvair	15-41	Body Styles	15-40
Seat Back Assembly (Right or Left)		Seat Back Lock, Folding Second - All	
Front - "A-39" Style Full Width and		"A & B" Station Wagon Styles Except	
Center Arm Rest	15-20	"55-65" Styles	15-51
Seat Back Assembly (Right or Left),		Seat Back Lock, Folding Second - Right	
Front - Two Door Style Standard Seat .	15-20	or Left Seat - "A-55" Split Seat	
Seat Back Assembly, Front - Four-Door		Option and all "65" Styles (Station Wagon) .	15-55
Style - Standard Full Width	15-19	Seat Back Lock, Front - Standard Full	
Seat Back Assembly, Rear - All Styles		Width - "A, B" X and Z" Body	15-20
Except "F and Z" with Folding Rear		Seat Back Lock, Front - Standard Full	
Seat Back	15-39	Width - "C & E" Body	15-21
Seat Back Assembly (Right or Left),		Seat Back Lock, Lock Control and Lock	
Standard Bucket - "F and Z" Styles . .	15-27	Rod, Strato - All Two-Door Except	
Seat Back Assembly, Strato Bucket - All		Reclining Strato	15-31
Except "F & Z" and Strato Reclining		Seat Back Lock Striker and Seat Back	
Seat Back	15-31	Lock, Reclining	15-33
Seat Back Assembly, Strato - Full		Seat Back Panel and Filler Panel, Folding	
Width 16639 Styles	15-29	Second - Right or Left Seat - "A-55"	
Seat Back Assembly, Strato - Full		Split Seat Option and All "65" Styles	
Width, All Styles Except 16639 Styles . .	15-28	(Station Wagon)	15-56
Seat Back Center Arm Rest and		Seat Back Panel Assembly or Trim	
Curtain, Rear	15-42	Assembly, Folding Third Seat Back	
Seat Back Center Arm Rest and Curtain		Panel - "A-55" Split Seat Option and	
Assembly, Front - Standard Full		All "65" Styles (Station Wagon)	15-57
Width	15-22	Seat Back Panel Assembly, Folding	
Seat Back Center Arm Rest and Curtain		Third - Station Wagon Rear Seats	15-47
Assembly, Front - Notch Down and		Seat Back Panel, Strato - Two-Door	
Strato Seat Back	15-23	Folding Seat Back	15-30
Seat Back Center Arm Rest and Support		Seat Back Panel, Strato - Four-Door	
Assembly, Front - Standard Full		Non Folding Seat Back	15-29
Width	15-22	Seat Back Panel Trim Assembly or Seat	
Seat Back Center Arm Rest Assembly,		Back Panel Assembly, Folding Third -	
Front - Notch Down and Strato Seat		"A-55" Split Seat Option and All "65"	
Back	15-23	Styles (Station Wagon)	15-57

Subject	Page No.	Subject	Page No.
Seat Back Positioning Unit, Front Reclining	15-33	Rear Quarter, "C-47" Styles	7-5
Seat Back Restraint Support, Front - Full Width	15-22	Sealing Strip, Front and Rear Door Bottom Auxiliary	6-5
Seat Back Stop Cable, Passenger Bucket - Chevrolet "F & Z" Styles	15-27	Sealing Strip, Front and Rear Door Bottom Drain Hole	6-4
Seat Back Trim and Spring Assembly, Folding Rear - Two Seat Styles, "A" Body Station Wagon (Except "65" Styles)	15-50	Sealing Strip, Tail Gate Drain Hole	9-11
Seat Back Trim and Spring Assembly, Folding Second - Right or Left Seat, "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-54	Second Seat Assembly, Folding - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-52
Seat Back Trim Assembly, Folding Second - Station Wagon Rear Seats	15-47	Second Seat Back Lock, Folding - All "A & B" Station Wagon Styles Except "55-65" Styles	15-51
Seat Back Trim Assembly, Folding Third - Station Wagon Rear Seats	15-46	Second Seat Back Lock, Folding - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Seat Back Trim, Panel and Linkage Assembly - Folding Second Seat - Station Wagon Rear Seats	15-48	Second Seat Back Trim and Spring Assembly, Folding - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagons)	15-54
Seat Belts and Shoulder Straps	15-58	Second Seat Cushion (Full Width or Split Seat) - Station Wagon Rear Seats	15-47
Seat Belt Retractor Floor Mount, Deluxe	15-50	Second Seat Cushion Assembly, Folding - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-53
Seat Belt Retractor Floor Mount, Standard	15-50	Second Seat Front Floor Pan Linkage, Folding - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Seat Cushion Assembly, Folding Second - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-53	Second Seat Rear Floor Pan Linkage, Folding - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Seat Cushion Assembly, Rear - Two Seat Styles - "A" Body Station Wagon (Except "65" Styles)	15-50	Second Seat Side Inner Linkage, Folding - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Seat Cushion, Folding Third - Station Wagon Rear Seats	15-46	Second Seat Side Outer Linkage, Folding - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55
Seat Cushion, Seat - All Styles Except "A-65"	15-39	Second Split Seat Back Inner Linkage Assembly, Folding	15-49
Seat Cushion (Full Width or Split Seat), Second - Station Wagon Rear Seats	15-47	Sectional Headlining - Flocked Type	11-5
Seat, Electric Four-Way Tilt	16-28	Selector Valves, Front and Rear Door Vacuum Lock	6-19
Seat, Electric Horizontal	16-25	Service Operations - Tail Lamp	16-43
Seat Front Floor Pan Linkage, Folding Second - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55	Shelf Trim, Compartment - All Except "E" Styles	14-15
Seat Linkage Lubrication, Folding	2-6	Shoe Polish and Dressings - Stain Removal	10-5
Seat Rear Floor Pan Linkage, Folding Second - Left or Right Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-55	Shoulder Straps and Seat Belts	15-58
Seat Side Outer Linkage, Folding Second - Right or Left Side - "A-55" Seat Option and All "65" Styles (Station Wagon)	15-55	Shroud Side Air Outlet Duct Assembly - "B, C & E" Except 26657	5-2
Seats, Six-Way Tilt Electric	16-33	Shroud Side Air Outlet Duct Door - "A, F, X & Z" and 26657	5-4
Sealing of Tail Lamps and Side Marker Lamps	16-40	Shroud Side Air Outlet Duct Door - "B, C & E" Except 26657	5-4
Sealing Operation, Exterior Molding	17-1	Shroud Side Air Outlet Duct Control Cable - "A, F, X & Z" and 26657	5-4
Sealing, Rear Quarter Inner Panel	7-1		
Sealing Strip Assembly, Vertical Inner -			

Subject	Page No.	Subject	Page No.
Shroud Side Air Outlet Duct Control Cable		Stationary Glass Removal	4-2
- "B, C & E" Except 26657	5-4	Stationary Glass Waterleak Correction . . .	4-6
Shroud Side Finishing Panel - "B, C & E"		Stationary Ventilator Assembly, Rear Door	
Except 26657	5-1	Window - "X-69" Style	6-89
Shroud Side Finishing Panel and Air		Stationary Ventilator Division Channel,	
Outlet Duct Assembly - "A, F, X & Z"		Rear Door Window - "X-69" Styles . . .	6-88
and 26657	5-2	Station Wagon Folding Rear Seats and	
Side and Center Trim Panels, Compart-		Floor Panels - "B" Body	15-43
ment Shelf - Cadillac "E" Styles	14-17	Station Wagon Folding Seats and Floor Panels	
Side Filler Panel, Compartment Pan -		- "A" Body (Except "65" Styles)	15-50
Station Wagon Rear Seats	15-44	Stop Cable, Passenger Bucket Seat Back -	
Side Finishing Panels, Compartment		Chevrolet "F & Z" Styles	15-27
Shelf - Oldsmobile and Buick "E"		Storage Tank, Front and Rear Door	
Styles	14-16	Vacuum Lock	6-21
Side Inner Linkage, Folding Second Seat		Strato Bucket Seat Back Assembly - All	
- Right or Left Seat - "A-55" Split		Except "F & Z" and Strato Reclining	
Seat Option and All "65" Styles (Station		Seat Back	15-31
Wagon)	15-55	Strato Bucket, Strato Full Width and	
Side Marker and Tail Lamps	16-40	Standard Bucket Seats	15-26
Side Roof Rail Weatherstrip and Retainer -		Strato Front Seats	15-26
Front and Rear Doors	6-7	Strato Full Width Seat Assembly	15-26
Silencer, Folding Top	13-21	Strato Full Width, Strato Bucket, and	
Six-Way Seat Adjuster Electric Motor -		Standard Bucket Seats	15-26
"B, C & E" Body Full Width	15-16	Strato Seat Back Assembly - Full	
Six-Way Seat Adjuster Front Vertical		Width - 16639 Styles	15-29
Gearnut - "B, C & E" Body Full		Strato Seat Back Assembly - Full Width -	
Width	15-16	All Styles Except 16639 Styles	15-28
Six-Way Seat Adjuster Horizontal Actuator		Strato Seat Back Head Restraint	15-30
- "B, C & E" Body Full Width	15-16	Strato Seat Back Head Restraint Support	
Six-Way Seat Adjuster Horizontal and		Guide Tube and Detent Spring	15-30
Vertical Drive Cables - "B, C & E"		Strato Seat Back Lock, Lock Control and	
Body Full Width	15-18	Lock Rod - All Two-Door Except	
Six-Way Seat Adjuster Lower and Upper		Reclining Strato	15-31
Channel and Plastic Slides - "B, C		Strato Seat Back Panel - Two-Door Folding	
& E" Body Full Width	15-17	Seat Back	15-30
Six-Way Seat Adjuster Major Components		Strato Seat Back Panel - Four-Door Non	
- "B, C & E" Body Full Width	15-15	Folding Seat Back	15-29
Six-Way Seat Adjuster Rear Vertical		Striker Adjustments, Tail Gate Lock	9-10
Gearnut - "B, C & E" Body Full		Striker Assembly, Tail Gate Lock	9-9
Width	15-17	Striker, Front and Rear Door Lock - All	
Six-Way Seat Adjuster Transmission -		Styles	6-11
"B, C & E" Body Full Width	15-18	Striker, Rear Compartment Lid Lock	8-9
Six-Way Tilt Seats, Electric	16-33	Striker, Rear Engine Compartment Latch -	
Spare Tire Cover Panel	14-13	Corvair	8-7
Specified Body Opening Clearance		Strip Assemblies, Outer - Rear Quarter	
Tolerances, Front and Rear Doors . . .	6-11	Window - All Closed Styles	7-4
Split Seat Back Inner Linkage Assembly,		Strip Assembly, Tail Gate Window Outer	
Folding Second	15-49	and Inner	9-11
Spring and Trim Assembly, Folding Rear		Style Number, Body	1-2
Seat Back - Two Seat Styles - "A"		Support Assembly and Center Arm Rest,	
Body Station Wagon (Except "65"		Front Seat Back - Standard Full Width .	15-22
Styles)	15-50	Support Assembly, Tail Gate	9-3
Spring Clips, Front and Rear Doors . . .	6-11	Support Guide (Head Restraint) and Detent	
Standard Bucket, Strato Bucket, and		Spring - Strato Seat Back	15-30
Strato Full Width Seats	15-26	Support Lubrication, Engine Compartment	
Standard Seat Belt Retractor Floor Mount .	15-50	Lid	2-8
Stationary Glass Installation (Short		Support, Front Seat Back Restraint - Full	
Method)	4-3	Width	15-22
Stationary Glass Installation (Extended		Switch, Jamb (Electric) - Tail Gate	9-7
Method)	4-4	Switch Lubrication, Door Jamb	2-3

Subject	Page No.	Subject	Page No.
T			
Tail Gate Assembly	9-3	Third Seat Cushion, Folding - Station Wagon Rear Seats	15-46
Tail Gate Drain Hole Sealing Strips	9-11	Tire Cover Panel, Spare	14-13
Tail Gate Filler Panel (Rear Floor To Assembly - 25000-26000 Series (Station Wagon Rear Seat)	15-44	Tools and Care, Exterior Molding	17-3
Tail Gate Fabric Cover	12-15	Top Adjustments, Folding - "A" Styles	13-34
Tail Gate Hinge Assembly	9-2	Top Adjustments, Folding - "B & C" Styles	13-38
Tail Gate Hinge Lubrication (Station Wagon)	2-5	Top Adjustments, Folding - "F" Styles	13-45
Tail Gate Inner Panel Access Hole Covers	9-2	Top Adjustments, Folding - "Z" Style	13-50
Tail Gate Inner Panel Cover	9-1	Top and Back Curtain Trim Assembly Installation	13-5
Tail Gate Inner Panel Water Deflector	9-1	Top and Back Curtain Trim Assembly Removal	13-2
Tail Gate Jamb Switch (Electric)	9-7	Top, Folding - Cleaning Procedure	10-3
Tail Gate Lock Assembly	9-9	Torque Rod Adjustments, Rear Compartment Lid	8-3
Tail Gate Lower Glass Run Channel	9-7	Torque Rod and Hinge Lubrication, Front Compartment	2-1
Tail Gate Lock Remote Control Assembly	9-8	Torque Rod Lubrication (Station Wagon), Tail Gate	2-5
Tail Gate Lock Striker Adjustments	9-10	Torque Rods, Front Compartment Lid - Corvair	5-7
Tail Gate Lock Striker Assembly	9-9	Torque Rods, Tail Gate	9-10
Tail Gate Lock Striker Lubrication (Station Wagon)	2-4	Torque Tube Assembly - Power Operated Four-Way Bucket Seat Adjuster	15-39
Tail Gate Opening Weatherstrips	9-11	Transmission and Motor Drive Belt and Pulleys - Power Operated Four-Way Bucket Seat Adjuster	15-37
Tail Gate Remote Control Inside Handle - "B" Styles	9-7	Transmission Assembly and Horizontal and Vertical Drive Cable - Power Operated Four-Way Bucket Seat Adjuster	15-38
Tail Gate Support Assembly	9-3	Transmission, Four-Way Seat Adjuster - "A" Body Full Width	15-12
Tail Gate Torque Rods	9-10	Transmission, Four-Way Seat Adjuster - Buick "B, C & E" Full Width	15-14
Tail Gate Torque Rod Lubrication (Station Wagon)	2-5	Transmission, Six-Way Seat Adjuster - "B, C & E" Body Full Width	15-18
Tail Gate Upper Glass Run Channels	9-12	Treatment, Wood Grain	1-7
Tail Gate Window Assembly (Manual or Electric)	9-4	Trim and Spring Assembly, Folding Rear Seat Back - Two Seat Styles "A" Body Station Wagon (Except "65" Styles)	15-50
Tail Gate Window Electric Regulator Motor	9-5	Trim and Spring Assembly, Folding Second Seat Back - Right or Left Seat - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-54
Tail Gate Window Inner and Outer Strip Assemblies	9-11	Trim Assemblies, Door (Except Corvair)	14-3
Tail Gate Window, Power Operated	16-20	Trim Assemblies, Door (Corvair)	14-6
Tail Gate Window Regulator (Manual or Electric)	9-4	Trim Assembly, Folding Top - Complete	13-1
Tail Gate Window Regulator Lubrication, Cams and Guides (Station Wagon)	2-5	Trim Assembly, Folding Third Seat Back - Station Wagon Rear Seats	15-46
Tail Gate Window Regulator Outside Handle (Manual or Electric)	9-6	Trim Assembly, Folding Second Seat Back - Station Wagon Rear Seats	15-47
Tail Lamps and Side Marker Lamps	16-40	Trim Assembly or Seat Back Panel Assembly, Folding Third Seat Back Panel - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-57
Tail Lamp Service Operations		Trim Assembly, Rear Quarter (2-Door Styles)	14-8
Acadian (Canadian)	16-43	Trim Cleaning	10-1
Beaumont (Canadian)	16-43	Trim, Compartment Shelf - All Except "E" Styles	14-15
Chevrolet	16-43		
Pontiac	16-45		
Oldsmobile	16-47		
Buick	16-49		
Cadillac	16-51		
Tar - Stain Removal	10-5		
Third Seat Back Panel Assembly, Folding - Station Wagon Rear Seats	15-47		
Third Seat Back Panel Trim Assembly or Seat Back Panel Assembly, Folding - "A-55" Split Seat Option and All "65" Styles (Station Wagon)	15-51		
Third Seat Back Trim Assembly, Folding - Station Wagon Rear Seats	15-46		

W

Water Deflector, Front and Rear Door	
Inner Panel	6-5
Water Deflector, Tail Gate Inner Panel . . .	9-1
Waterleak Correction - Stationary Glass .	4-6
Weatherstrip and Retainer - Front and	
Rear Door Side Roof Rail	6-7
Weatherstrip, Front and Rear Door	6-2
Weatherstrip, Front and Rear Door Center	
Pillar - "C-69" Styles	6-11
Weatherstrip, Front Compartment Lid	
Gutter - Corvair	5-10
Weatherstrip, Front Door Ventilator -	
"Z" Styles	6-56
Weatherstrip, Rear Compartment	8-11
Weatherstrip, Tail Gate Opening	9-11
Wedge Plates, Front Door - "67" Styles .	6-69
Wheelhouse Cover Panel, Rear Quarter -	
Right Side ("B" Body Station Wagon) . . .	14-11

Subject	Page No.	Subject	Page No.
Wheelhouse Trim Cover Panel - Right Side ("A" Body Station Wagon)	14-14	Window Front Glass Run Channel, Rear Quarter - All Closed Styles	7-4
Window Adjustments, Front Door - "B" Closed Styles	6-58	Window Front Guide and Bracket Assembly, Rear Door - "A-39" Styles	6-90
Window Adjustments, Front Door - "Z" Styles	6-64	Window Front Guide and Guide Plate, Rear Door - 68069 and 68169 Styles	6-90
Window Adjustments, Rear Door - "A-39" Styles	6-84	Window Front Guide, Front Door - 16647 and 26657 Styles	6-66
Window Adjustments, Rear Quarter - "A-27 & 77", "B-11" and "X-27" Styles	7-3	Window Front Guide, Front Door - "E" Styles	6-67
Window Assembly, Front Door - 16647 and 26657 Styles	6-60	Window Front Guide, Front Door - "F" Styles	6-67
Window Assembly, Front Door - "A" Hardtop and Convertible Styles	6-57	Window Front Guide, Rear Quarter - "Z" Hardtop and Convertible and "E-87" Styles	7-22
Window Assembly, Front Door - "A & X" Closed Styles	6-56	Window Front Guide, Rear Quarter - "B-C 47-57-67-87" Styles	7-18
Window Assembly, Front Door - "B" Closed Styles	6-58	Window Guide (Front or Rear) - All "B-C 39" and "C 49-69" Styles Except 68069-68169	6-90
Window Assembly, Front Door - "B & C" Hardtop and Convertible Style Except 16647 and 26657 Styles	6-58	Window Guide Assembly, Rear Quarter - "A" Hardtop and Convertible Styles	7-24
Window Assembly, Front Door - "E" Styles	6-61	Window Guide Assembly, Rear Quarter - "F" Styles	7-24
Window Assembly, Front Door - "F" Styles	6-63	Window Glass Run Channel, Front Door - "A & X" Closed Styles	6-67
Window Assembly, Front Door - "Z" Styles	6-64	Window Glass Run Channel, Front Door - "B" Closed Styles	6-68
Window Assembly, Rear Door - 68069 and 68169 Styles	6-86	Window Glass Run Channel, Rear Quarter - "E-47" Styles	7-24
Window Assembly, Rear Door - "A-39" Styles	6-83	Window Inner and Outer Strip Assembly, Tail Gate	9-11
Window Assembly, Rear Door - "A" Closed Styles	6-83	Window Outer Strip Assemblies, Rear Quarter - All Closed Styles	7-4
Window Assembly, Rear Door - "B" Closed Styles	6-84	Windows, Power Operated	16-2
Window Assembly, Rear Door - All "B-C 39" Styles and All "C-49" and "69" Styles, Except 68069 and 68169	6-84	Window, Power Operated Tail Gate	16-20
Window Assembly, Rear Door - "X-69" Styles	6-89	Window Rear Glass Run Channel, Rear Quarter - All Closed Styles	7-3
Window Assembly, Rear Quarter - All Hardtop Styles (Except "B-C" Styles)	7-5	Window Rear Guide and Guide Plate Assembly, Front Door - "B & C" Styles, Except 16647 and 26657 Styles	6-66
Window Assembly, Rear Quarter - "A-27 & 77", "B-11 and X-27" Styles	7-2	Window Rear Guide, Front Door - 16647 and 26657 Styles	6-67
Window Assembly, Rear Quarter - "A-37, 67 & 87" Styles	7-5	Window Rear Guide, Front Door - "A" Hardtop and Convertible Styles	6-66
Window Assembly, Rear Quarter - "B & C-47, 57, 67 & 87" Styles	7-12	Window Rear Guide, Front Door - "E" Styles	6-67
Window Assembly, Rear Quarter - "E-47" Styles	7-9	Window Rear Guide, Front Door - "F" Styles	6-67
Window Assembly, Rear Quarter - "E-87" Styles	7-8	Window Rear Guide, Front Door - "Z" Styles	6-67
Window Assembly, Rear Quarter - "F-37 & 67" Styles	7-7	Window Rear Guide, Rear Door - "A-39" Styles	6-90
Window Assembly, Rear Quarter - "Z-37" & 67" Styles	7-12	Window Rear Guide, Rear Quarter - "Z" Hardtop and Convertible and "E-87" Styles	7-22
Window Assembly, Tail Gate (Manual or Electric)	9-4	Window Regulator Cams and Guides Lubrication, Rear Quarter	2-4
Window Electric Regulator Motor, Tail Gate	9-5	Window Regulator, Electric - "A, B & C" Hardtop and Convertible Style Front Door	6-65

Subject	Page No.	Subject	Page No.
Window Regulator Electric Motor, Front and Rear Door	6-26	Window Regulator, Rear Door - Manual and Electric - All "A, B & C" Styles	6-89
Window Regulator Electric Motor Removal, Rear Door - All Styles	6-90	Window Regulator, Rear Quarter (Manual and Electric) "A, E, F & Z" Hardtop and Convertible Styles	7-16
Window Regulator Handle, Rear Quarter . .	14-7	Window Regulator, Rear Quarter (Manual and Electric) - "A, B & X" Closed Styles	7-17
Window Regulator Lubrication, Cams and Guides (Station Wagon), Tail Gate	2-5	Window Regulator, Rear Quarter (Manual and Electric) - "B & C - 47, 57, 67 & 87" Styles	7-15
Window Regulator Lubrication, Cams and Guides on Styles with Upper Frames, Door	2-3	Window Regulator Outside Handle, Tail Gate (Manual or Electric)	9-6
Window Regulator Lubrication, Cams and Guides on Styles Without Upper Frames, Door	2-4	Window Regulator, Tail Gate (Manual or Electric)	9-4
Window Regulator, Manual and Electric - 16647, 26657 and "F" Front Door Styles	6-66	Window Stationary Ventilator Assembly, Rear Door - "X-69"	6-89
Window Regulator, Manual and Electric - Front Door "E" Styles	6-66	Window Stationary Ventilator Division Channel, Rear Door - "X-69" Styles	6-88
Window Regulator, Manual - "A, B & C Hardtop and Convertible Front Door Styles	6-65	Window Vertical Inner Sealing Strip Assembly, Rear Quarter - "C-47" Styles . . .	7-5
Window Regulator, Manual - "X, A & B" Closed Style Front Doors	6-64	Wine, Liquor, Fruit, Fruit Stains - Stain Removal	10-4
Window Regulator, Manual - "Z" Style Front Doors	6-66	Wood Grain Treatment	1-7
Window Regulator, Rear Doors - "X-69" Styles	6-90		