

## SECTION 18

## INDEX

Subject	Page No.	Subject	Page No.
<b>A</b>			
Access Hole Cover, Dual Acting Tail		Alignment, Underbody	
Gate Inner Panel . . . . .	9-4	Corvair "Z" Styles . . . . .	3-1
Access Hole Cover, Single Acting Tail		Camaro and Firebird "F" Bodies . . . . .	3-5
Gate Inner Panel . . . . .	9-28	Chevy Nova and Acadian "X" Bodies . . . . .	3-5
Actuator Assembly, Folding Top -		Appliques and Moldings, Door Trim Panel . . . . .	14-7
"Z" Styles . . . . .	13-35	Appliques and Moldings, Rear Quarter	
Actuator or Electric Solenoid, Front and		Trim Panel . . . . .	14-13
Rear Door Vacuum . . . . .	6-17	Arm Rest (Center) and Curtain Assembly -	
Adhesive Caulked Glass - All Styles . . . . .	4-1	Standard Full Width Seat Back . . . . .	15-32
Adjuster Horizontal Actuator Assembly,		Arm Rest (Center) and Support Assembly -	
Strato - Full Width or Bucket and		Standard Full Width Seat Back . . . . .	15-34
Standard Bucket Seats . . . . .	15-40	Arm Rests, Door . . . . .	14-1
Adjuster Jackscrew - Strato - Full Width		Arm Rest, Rear Quarter . . . . .	14-7
or Bucket and Standard Bucket Seats . . . . .	15-40	Auxiliary Sealing Strip, Front and Rear	
Adjuster Mechanism Lubrication,		Door Bottom . . . . .	6-4
Folding Seat . . . . .	2-7	Auxiliary Seat Adjustments, Rear -	
Adjuster Vertical Gearnut - Strato - Full		Cadillac Limousine Styles . . . . .	15-54
Width or Bucket and Standard Bucket		Auxiliary Seat Assembly, Rear -	
Seats . . . . .	15-40	Cadillac Limousine Styles . . . . .	15-53
Adjusting Plate, Folding Top -		Auxiliary Seat Lower Support Assembly,	
"Z" Body . . . . .	13-49	Rear - Cadillac Limousine Styles . . . . .	15-56
Adjustment of Front Roof Rail,		<b>B</b>	
Folding Top Adjustments "A, B & C"		Back Curtain Assembly - Complete . . . . .	13-39
Styles . . . . .	13-39	Ball Point Ink - Stain Removal . . . . .	10-5
Adjustment of Front Roof Rail,		Blood - Stain Removal . . . . .	10-3
Folding Top - "F" Body . . . . .	13-43	Body Opening Clearance Tolerances,	
Adjustment of Front Roof Rail,		Specified - Front and Rear Doors . . . . .	6-10
Folding Top - "Z" Body . . . . .	13-49	Bucket Seat Back Assembly - Standard	
Adjustment of Front Roof Rail Guide,		Bucket Seat "F & Z" Styles . . . . .	15-41
Folding Top Adjustments - "A, B & C"		Bucket Seat (front) Back Stop Cable,	
Styles . . . . .	13-39	Passenger - Chevrolet "F & Z" Styles . . . . .	15-41
Adjustment of Front Roof Rail Wedge		<b>C</b>	
Plate, Folding Top - "Z" Body . . . . .	13-49	Cams and Guides Lubrication, Door	
Adjustment of Male Hinge, Folding Top -		Window Regulator - Styles without	
"Z" Body . . . . .	13-50	Upper Frames . . . . .	2-4
Adjustment of Top Control Link, Folding		Cams and Guides Lubrication, Rear	
Top, - "A, B & C Styles . . . . .	13-39	Quarter Window Regulator . . . . .	2-5
Adjustment of Top Control Link,		Cam, Inner Panel, Front Door - All	
Folding Top - "F" Body . . . . .	13-44	Styles Except "A and X-69" Styles . . . . .	6-58
Adjustment of Top Control Link,		Cam, Rear Door Inner Panel - All	
Folding Top - "Z" Body . . . . .	13-49	Except "A and X-69" Styles . . . . .	6-88
Adjustment of Top at Male Hinge,		Cams, Sector Gear and Window Regulator	
Folding Top - "F" Body . . . . .	13-44	Lubrication, Tail Gate (All Station	
Air Duct Outlet and Door, Shroud Side -		Wagons) . . . . .	2-6
Buick and Cadillac "E" Styles . . . . .	5-7	Cams and Window Regulator Lubrication,	
Air Outlet and Door, Shroud Center		Door - on Styles with Door Upper	
Duct Upper -		Frames . . . . .	2-3
"B and C" Styles . . . . .	5-4	Candy - Stain Removal . . . . .	10-4
"A and G" Styles . . . . .	5-4	Carpets, Floor - Cleaning . . . . .	10-3
"F" Styles . . . . .	5-4	Catch Clips, Folding Top . . . . .	13-38
Air Outlet Duct and Shroud Side Finishing		Catsup - Stain Removal . . . . .	10-5
Panel - "Z-67" Styles . . . . .	5-6		

Subject	Page No.
Center Arm Rest and Curtain Assembly - Notch Down Seat Back and Strato Seat . . .	15-34
Center Arm Rest and Curtain Assembly - Standard Full Width Seat Back . . . . .	15-32
Center Arm Rest and Support Assembly - Standard Full Width Seat Back . . . . .	15-34
Center Duct Upper Air Outlet and Door, Shroud - "B and C" Styles . . . . .	5-4
"A and G" Styles . . . . .	5-4
"F" Styles . . . . .	5-4
Center Finishing Panel, Compartment Shelf - Oldsmobile and Buick "E" Styles . . . . .	14-20
Center Pillar Trim ("A, B & C" Four- Door Hardtop Styles) . . . . .	14-19
Center Pillar Upper and Lower Trim ("A & X" Four-Door Closed Styles) . . .	14-19
Center Pillar Upper and Lower Trim - ("B & C" Four-Door Closed Styles) . . .	14-19
Center Pillar Weatherstrips, Front and Rear Doors - "C-69" Styles . . . . .	66-9
Center and Side Trim Panels, Compartment Shelf - Cadillac "E" Styles . . . . .	14-20
Channel (Lower or Upper) and Plastic Slides, Six-Way Seat Adjuster - "B-C & E" Body Full Width . . . . .	15-21
Checking Procedure, Four-Way Tilt Seat - Electrical . . . . .	16-34
Checking Procedures, Power Windows - Electrical . . . . .	16-3
Checking Procedure, Tail Gate Window - Electrical . . . . .	16-13
Chewing Gum - Stain Removal . . . . .	10-4
Circuit Checking Procedures, Electric Seat Back Lock Release . . . . .	16-58
Circuit Checking Procedures, Power Window . . . . .	16-5
Circuit Checking Procedures, Six-Way Tilt Seat - Electrical . . . . .	16-38
Clips, Front and Rear Door Spring . . . . .	6-10
Compartment Door Hinge Lubrication, Instrument Panel . . . . .	2-2
Compartment Door, Instrument Panel - Buick "A & E" Styles . . . . .	5-9
Compartment Door Lock Cylinder and Lock, Instrument Panel - Buick "A & E" Styles, All Chevrolet Styles . . . . .	5-9
Compartment Floor Panel Assembly (at Kick-Up) Rear Seat All Styles . . .	15-62
Compartment, Front - Corvair . . . . .	5-11
Compartment Front and Shelf Panel Trim Assembly - "Z" Styles with Stationary or Folding Rear Seat Back . . . . .	14-21
Compartment Hinge Lubrication, Rear . . .	2-8
Compartment Lid, Front - Corvair . . . . .	5-11
Compartment Lid Gutter Weatherstrip, Front - Corvair . . . . .	5-14
Compartment Lid Hinge and Torque Rod - Lubrication, Front . . . . .	2-1

Subject	Page No.
Compartment Lid Lock Assembly, Front - Corvair . . . . .	5-13
Compartment Lid Lock Cylinder Assembly, Front - Corvair . . . . .	5-13
Compartment Lid Lock - Lubrication, Front . . . . .	2-1
Compartment Lid Lock Lubrication, Compartment Lid Lock Lubrication, Rear . .	2-8
Compartment Lid Lock Striker, Front - Corvair . . . . .	5-13
Compartment Lid, Rear - All Styles Except Corvair . . . . .	8-1
Compartment Lid Support Lubrication, Engine . . . . .	2-8
Compartment Lid Torque Rods, Front - Corvair . . . . .	5-12
Compartment Shelf Center Finishing Panel - Oldsmobile and Buick "E" Styles . . .	14-20
Compartment Shelf Side and Center Trim Panels - Cadillac "E" Styles . . . . .	14-20
Compartment Shelf Side Finishing Panels - Oldsmobile and Buick "E" Styles . . . . .	14-20
Compartment Shelf Trim Assembly - All Styles Except "E & F" Styles and "F-37" Styles with Folding Rear Seat . .	14-20
Compartment Shelf Trim Assembly - "F-37" Styles with Folding Rear Seat . .	14-23
Components, Ventilation System - Non- Air Conditioning . . . . .	5-1
Connecting Rod and Lock Remote Control, Front Door - All Styles . . . . .	6-55
Control Arm Knob, Manually Operated Seat Adjuster . . . . .	15-6
Convertible Top Hinge Mechanism Lubrication . . . . .	2-7
Covers, Instrument Panel - Chevrolet "A, X & Z" and Pontiac "F" Styles . . .	5-10
Cover Panel, Rear Quarter Wheelhouse - Right Side ("B" Body Station Wagon Styles) . . . . .	14-13
Cover Panel, Spare Tire (Station Wagon Styles) . . . . .	14-14
Cover Panel, Wheelhouse Trim - Right Side (All "A" Body Station Wagon Styles) . . . . .	14-15
Cover, Single Acting Tail Gate Inner Panel . . . . .	9-25
Cross Over Harness, Power Windows - Electrical . . . . .	16-2
Curtain Assembly, Back - Complete . . .	13-19
Cushion Assembly, Folding Second Seat - "55, 56, 65, 66" Styles . . . . .	15-66
Cushion, Second Seat - (Full Width or Split Seat) Rear - All Styles . . . . .	15-62
Cushion Trim Assembly, Folding Third Seat - "65-66" Styles . . . . .	15-71
Cut-Out Switch, Power Windows - Electrical . . . . .	16-3
Cylinder Assembly, Front Compartment Lid Lock - Corvair . . . . .	5-13

Subject	Page No.	Subject	Page No.
Cylinder Assy, Rear Compartment Lid		Drive Cables - Horizontal or Front	
Lock - All Styles . . . . .	8-7	Vertical, Six-Way Seat Adjuster - Buick,	
		Oldsmobile and Cadillac 60-40 Seats . . . . .	15-23
<b>D</b>		Drive Cables, Horizontal and Vertical	
Dealer Relocation Provisions, Front Seat . . . . .	15-3	Four-Way Seat Adjuster - "A" Body	
Deluxe Front Seat Belt Retractor -		Full Width . . . . .	15-16
Floor Mount . . . . .	15-73	Drive Cables - Horizontal and Vertical,	
Door Arm Rests . . . . .	14-1	Four-Way Seat Adjuster - Buick "B-C	
Door Bottom Auxiliary Sealing Strip,		& E" Body Full Width . . . . .	15-19
Front and Rear Door . . . . .	6-4	Drive Cables, Horizontal and Vertical	
Door Bottom Drain Hole Sealing Strips,		and Transmission Assembly - Strato	
Front and Rear Doors . . . . .	6-4	Full Width or Bucket and Standard	
Door Hinge Assembly Lubrication,		Bucket Seats . . . . .	15-39
Front . . . . .	2-2	Drive Cables - Rear Vertical, Six-Way	
Door Hinge Assembly Lubrication, Rear . . . . .	2-2	Seat Adjuster - Buick, Oldsmobile and	
Door Hinge, Front - All Styles . . . . .	6-54	Cadillac 60-40 Seats . . . . .	15-23
Door Hinges, Front - All Styles . . . . .	6-53	Dual Acting Tail Gate . . . . .	9-1
Door Hinge Lubrication, Gas Tank Filler	2-7		
Door Hinge Lubrication, Instrument		<b>E</b>	
Panel Compartment . . . . .	2-2	Electric Actuator Assembly and Seat	
Door Hinges, Rear - All Styles . . . . .	6-80	Back Lock - Cadillac Two-Door Styles	
Door Inside Handles . . . . .	14-3	with Standard Full Width Seat . . . . .	15-29
Door, Instrument Panel Compartment -		Electric Back Window Grid Defogger . . . . .	16-56
Buick "A & E" Styles . . . . .	5-9	Electric Door Lock . . . . .	16-60
Door Jamb Switch Lubrication . . . . .	2-3	Electric Motor, Four-Way Seat Adjuster -	
Door Lock Cylinder and Lock, Instrument		"A" Body Full Width . . . . .	15-15
Panel Compartment - Buick "A & E"		Electric Motor, Four-Way Seat Adjuster -	
Styles, All Chevrolet Styles . . . . .	5-9	Buick "B-C & E" Body Full Width . . . . .	15-17
Door Lock, Electric . . . . .	16-60	Electric Motor, Front and Rear Door	
Door Lock Fork Bolt Lubrication . . . . .	2-3	Window Regulator Removal - All	
Door Locking Mechanism and Lock		Styles Except "E" Styles . . . . .	6-24
Parts Lubrication . . . . .	2-3	Electric Motor Removal, Front and Rear	
Door Outside Mirror Remote Controls		Door Window Regulator - "E" Styles . . . . .	6-30
and Escutcheon . . . . .	14-3	Electric Motor, Six-Way Seat Adjuster -	
Door Outside Remote Control Mirror,		"B-C & E" Body Full Width . . . . .	15-20
Front - All Styles Without Door		Electric Motor, Six-Way Seat Adjuster -	
Ventilators . . . . .	6-58	Buick, Oldsmobile and Cadillac	
Door Pull Handles . . . . .	14-1	60-40 Seats . . . . .	15-22
Door Removal and Installation - All		Electric Motor, Two-Way Seat Adjuster -	
Styles . . . . .	6-53	"C" Body Full Width . . . . .	15-14
Door Trim . . . . .	14-1	Electric Regulator Motor Assembly,	
Door Trim Assemblies . . . . .	14-4	Single Acting Tail Gate Window . . . . .	9-33
Door Trim Panel Moldings and		Electric Seat Back Lock - Cadillac Two-	
Appliques . . . . .	14-7	Door Styles with Standard Full Width	
Door Wedge Plates, Front Door -		Seats . . . . .	15-29
"67" Styles . . . . .	6-79	Electric Seat Back Lock Release . . . . .	16-58
Door Window Regulator and Cams		Electrical Checking Procedure, Folding	
Lubrication on Styles with Door Upper		Top Hydro-Lectric System . . . . .	13-30
Frames . . . . .	2-3	Electrical Checking Procedure - Power	
Door Window Regulator Cams and Guides		Window Circuit . . . . .	16-5
Lubrication - Styles without Upper		Electrical Checking Procedures, Power	
Frames . . . . .	2-4	Windows . . . . .	16-3
Drain Hole Sealing Strips - Dual Acting		Electrical Tail Gate Window Circuit . . . . .	16-12
Tail Gate . . . . .	9-21	Engine Compartment Latch Striker -	
Drain Hole, Sealing Strips, Front and		Corvaire Styles . . . . .	8-7
Rear Door Bottom . . . . .	6-4	Engine Compartment Lid Latch -	
Drain Hole Sealing Strips -		Corvaire Styles . . . . .	8-4
Single Acting Tail Gate . . . . .	9-37	Engine Compartment Lid Support -	
		Corvaire Styles . . . . .	8-4

Subject	Page No.	Subject	Page No.
Engine Compartment Lid Support		Finishing Panel, Shroud Side - "F" Styles	5-6
Lubrication . . . . .	2-8	Floor Carpets - Cleaning . . . . .	10-3
Escutcheon and Remote Controls,		Floor Pan Linkage, Folding Second Seat	
Door Outside Mirror . . . . .	14-3	Front - "55, 56, 65, 66" Styles . . . . .	15-69
Exterior Moldings -		Floor Pan Linkage, Folding Second Seat	
Chevrolet "A" Body . . . . .	17-12	Rear - "55, 56, 65, 66" Styles . . . . .	15-69
"B" Body . . . . .	17-23	Fluid Control Valve, Folding Top	
"F" Body . . . . .	17-30	Hydro-Lectric System . . . . .	13-29
"X" Body . . . . .	17-34	Folding Rear Seat Back - "F" Body	
"Z" Body . . . . .	17-39	Styles . . . . .	15-51
Pontiac "A" Body . . . . .	17-44	Folding Rear Seat Back - "Z" Body	
"B" Body . . . . .	17-53	Styles . . . . .	15-52
"F" Body . . . . .	17-59	Folding Rear Seat Back Linkage -	
Oldsmobile "A" Body . . . . .	17-69	"Z" Body Styles . . . . .	15-52
"B-C" Body . . . . .	17-80	Folding Rear Seat Back Lock -	
"E" Body . . . . .	17-86	"F" Body Styles . . . . .	15-52
Buick "A" Body . . . . .	17-92	Folding Rear Seat Back Lock -	
"B-C" Body . . . . .	17-102	"Z" Body Styles . . . . .	15-52
"E" Body . . . . .	17-108	Folding Seat Adjuster Mechanism	
Cadillac "C" Body . . . . .	17-113	Lubrication . . . . .	2-7
"D" Body . . . . .	17-118	Folding Seat Linkage Lubrication . . . . .	2-7
"E" Body . . . . .	17-121	Folding Seats and Floor Panels -	
Acadian "X" Body (Canadian) . . . . .	17-124	"55, 56, 65, 66" Styles . . . . .	15-65
Beaumont "A" Body (Canadian) . . . . .	17-128	Folding Second Seat Assembly -	
Pontiac "B" Body (Canadian) . . . . .	17-134	"55, 56, 65, 66" Styles . . . . .	15-66
Exterior Molding Sealing Operation . . . . .	17-4		
Exterior Molding Tools and Care . . . . .	17-4	Assembly (Full Width Seat - Right	
Exterior Molding Zinc Anode Clips . . . . .	17-5	or Left Side Split Seat -	
		Outer Linkage Only) . . . . .	15-63
<b>F</b>		Folding Second Seat Back Lock (Full	
Fabric Roof Cover (All Styles Except		Width or Split Seat) - All "A & B"	
Station Wagons) . . . . .	12-1	Styles (Except "A-55, 56, 65, 66"	
Fabric Roof Cover		Styles) . . . . .	15-64
(Station Wagon Styles) . . . . .	12-10	Folding Second Seat Back Lock (Full	
Fabric Roof Cover and		Width or Split Seat) - All "A & B"	
Folding Top - Cleaning . . . . .	10-3	Styles (Except "A-55, 56" Styles	
Fabric Cover, Tail Gate . . . . .	12-13	with Split Seat Option and "65-66"	
Feed Harness for Rear Doors or		Styles . . . . .	15-65
Quarter Windows, Power Windows -		Folding Second Seat Back Lock -	
Electrical . . . . .	16-2	"55, 56, 65, 66" Styles . . . . .	15-70
Filler Door Hinge Lubrication,		Folding Second Seat Back Panel and	
Gas Tank . . . . .	2-7	Filler Panel - "55, 56, 65, 66"	
Filler Panel Assembly, Rear Floor to		Styles . . . . .	15-70
Tail Gate, Compartment Pan Side		Folding Second Seat Back Trim, Panel	
Filler Panels - "B" Body Two-Seat		and Linkage Assembly (Full Width or	
and Three Seat Styles . . . . .	15-57	Split Seat) - All Styles . . . . .	15-63
Filler Panel, Rear Floor Rear Seats -		Folding Second Seat Back Trim and	
All Styles . . . . .	15-62	Spring Assembly (Full Width or Split	
Filling of Hydro-Lectric Reservoir,		Seat) - All Styles . . . . .	15-62
Folding Top . . . . .	13-33	Folding Second Seat Back Trim and	
Finishing Panel and Air Duct Outlet,		Spring Assembly - "55, 56, 65, 66"	
Shroud Side - "Z-67" Styles . . . . .	5-6	Styles . . . . .	15-68
Finishing Panel, Compartment Shelf		Folding Second Seat Cushion Assembly -	
Center - Oldsmobile and Buick "E"		"55, 56, 65, 66" Styles . . . . .	15-66
Styles . . . . .	14-20	Folding Second Seat Front Floor Pan	
Finishing Panel, Compartment Shelf		Linkage - "55, 56, 65, 66" Styles . . . . .	15-89
Side - Oldsmobile and Buick "E"		Folding Second Seat Rear Floor Pan	
Styles . . . . .	14-20	Linkage - "55, 56, 65, 66" Styles . . . . .	15-69
Finishing Panel, Shroud Side - "A, G,		Folding Second Seat Side Inner Linkage -	
B, C, X and Z-37" Styles . . . . .	5-4	"55, 56, 65, 66" Styles . . . . .	15-69

Subject	Page No.	Subject	Page No.
Folding Second Seat Side Outer Linkage - "55, 56, 65, 66" Styles . . . . .	15-69	Four-Way Seat Adjuster Major Components - Buick "B-C & E" Body Full Width . .	15-17
Folding Second Split Seat Back Inner Linkage Assembly . . . . .	15-64	Four-Way Seat Adjuster Transmission - "A" Body Full Width . . . . .	15-17
Folding Third Seat Back Lock - All "A & B" Body Three Seat Styles . . . .	15-61	Four-Way Seat Adjuster Transmission - Buick "B-C & E" Body Full Width . .	15-19
Folding Third Seat Back Lock - "65-66" Styles . . . . .	15-72	Four-Way Seat Adjuster Vertical and Horizontal Drive Cables - "A" Body Full Width . . . . .	15-16
Folding Third Seat Back Panel Assembly - Three Seat Styles . . . . .	15-61	Four-Way Seat Adjuster Vertical and Horizontal Drive Cables - Buick "B-C & E" Body Full Width . .	15-19
Folding Third Seat Back Trim Assembly - Three Seat Style . . . . .	15-61	Four-Way Seat Adjuster Vertical Jackscrew - "A" Body Full Width . .	15-16
Folding Third Seat Cushion - Three Seat Style Folding Third Seat Cushion Panel Assembly and Support - Three Seat Style . . . . .	15-60	Four-Way Tilt Seat, Electrical Checking Procedure . . . . .	16-34
Folding Third Seat Cushion Trim Assembly - "65-66" Styles . . . . .	15-71	Four-Way Tilt Seat, Power Seats - Electrical . . . . .	16-33
Folding Third Seat and Floor Panel Assembly - "65-66" Styles . . . . .	15-70	Front Compartment - Corvair . . . . .	5-11
Folding Third Seat Lock Trim Assembly or Seat Back Panel Assembly - "65-66" Styles . . . . .	15-71	Front Compartment Lid - Corvair . . . .	5-11
Folding Top Adjustments - "A, B & C" Styles . . . . .	13-38	Front Compartment Lid Gutter Weatherstrip - Corvair . . . . .	5-14
Folding Top Adjustment - "F" Body . . . .	13-43	Front Compartment Lid Hinge and Torque Rod Lubrication . . . . .	2-1
Folding Top Adjustments - "Z" Body . . . .	13-48	Front Compartment Lid Lock Assembly - Corvair . . . . .	5-13
Folding Top Catch Clips . . . . .	13-38	Front Compartment Lid Lock Cylinder Assembly - Corvair . . . . .	5-13
Folding Top Cover and Back Curtain Installation - Complete . . . . .	13-9	Front Compartment Lid Lock Lubrication . . . . .	2-1
Folding Top Cover and Back Curtain Removal - Complete . . . . .	13-1	Front Compartment Lid Lock Striker - Corvair . . . . .	5-13
Folding Top Cover - Less Back Curtain . .	13-13	Front Compartment Lid Torque Rods - Corvair . . . . .	5-12
Folding Top and Fabric Roof Cover - Cleaning . . . . .	10-3	Front Door Hinge Assembly Lubrication . .	2-2
Folding Top Lift Cylinder, Hydro- Lectric System . . . . .	13-33	Front Door Hinges - All Styles . . . . .	6-53
Folding Top Manual Lift Assembly - "A, F & Z" Styles . . . . .	13-37	Front Door Window Harness, Power Windows - Electrical . . . . .	16-2
Folding Top Operation - Hydro-Lectric System . . . . .	13-28	Front Guide and Bracket Assembly, Rear Door Window - "A-39" Styles . . .	6-97
Folding Top Silencer Assembly - Cadillac Styles . . . . .	13-7	Front Guide, Front Door Window - "A-37, 67 and 87" Styles and "G-57" Styles . . . . .	6-76
Folding Top Trim Assembly - Complete . .	13-1	Front Guide, Front Door Window - "B and C" Hardtop & Convertible Styles . . . . .	6-76
Fork Bolt Lubrication, Door Lock . . . .	2-3	Front Guide, Front Door Window - "E" Styles . . . . .	6-77
Fork Bolt Lubrication, Tail Gate Lock (Right and Left) - Station Wagon Styles with Dual Acting Tail Gate . . . . .	2-5	Front Guide, Front Door Window - "F" Styles . . . . .	6-77
Foot Rest Assembly - Cadillac 68169 Style . . . . .	15-34	Front Guide, Rear Door Window - "B-39 and C-39, 49 & 69" Styles . . . .	6-97
Four-Way Seat Adjuster Electric Motor - "A" Body Full Width . . . . .	15-15	Front Headlining Assembly . . . . .	11-5
Four-Way Seat Adjuster Electric Motor - Buick "B-C & E" Body Full Width . .	15-17	Front Panel Rear Compartment - Buick & Olds. "E" Styles . . . . .	8-3
Four-Way Seat Adjuster Horizontal Actuator - "A" Body Full Width . . . .	15-16	Front and Rear Panel Assembly, Luggage Compartment* Two Seat Styles . . . . .	15-58
Four-Way Seat Adjuster Horizontal Actuator - Buick "B-C & E" Body Full Width . .	15-19	Front and Rear Panel Hinge Assembly, Luggage Compartment - Two Seat Styles .	15-60
Four-Way Seat Adjuster Major Components - "A" Body Full Width . . . . .	15-15		

Subject	Page No.
Front Roof Rail, Folding Top	
Adjustment - "Z" Body . . . . .	13-49
Front Roof Rail Lock Adjustment,	
Folding Top - "A, B & C" Styles . . .	13-39
Front Roof Rail Lock Adjustment,	
Folding Top - "F" Body . . . . .	13-43
Front Roof Rail Lock Adjustment,	
Folding Top - "Z" Body . . . . .	13-49
Front Roof Rail Lock Assembly,	
Folding Top Adjustments	
"A, B & C" Styles . . . . .	13-39
Front Roof Rail Lock Assembly, Folding	
Top Adjustments - "F" Body . . . . .	13-43
Front Roof Rail Lock Assembly, Folding	
Top - "Z" Body . . . . .	13-49
Front Seat Adjuster Assembly - Manual -	
Full Width . . . . .	15-8
Front Seat Adjuster Assembly - Power -	
Full Width . . . . .	15-12
Front Seat Assembly - Manual -	
Full Width . . . . .	15-8
Front Seat Assembly - Power -	
Full Width . . . . .	15-10
Front Seat Assembly - Standard Full	
Width and 60-40 Seats . . . . .	15-7
Front Seat Assembly, Strato Full Width . .	15-36
Front Seat Back Assembly, All "39"	
Style Full Width and Buick, Oldsmobile	
and Cadillac 60-40 Seat with Notch Down	
Center Arm Rest . . . . .	15-27
Front Seat Back Assembly, Four-door -	
Full Width . . . . .	15-26
Front Seat Back Assembly, Seat Back	
Locks - "A, B, X & Z" Body Two-Door	
Styles with Standard Full Width . . . . .	15-28
Front Seat Back Assembly, Seat Back	
Locks - "C & E" Body Two-Door Styles	
with Standard Full Width and 60-40	
Seat . . . . .	15-28
Front Seat Back Assembly, Two-door	
Style with Standard or Notch Down	
Seat . . . . .	15-27
Front Seat Dealer Relocation Provisions .	15-3
Front and Shelf Panel Trim Assembly,	
Compartment - "Z" Styles with	
Stationary or Folding Rear Seat Back . .	14-21
Front Trim Panel, Rear Quarter - Right	
or Left Side ("A" Body Station	
Wagons) . . . . .	14-14
Front Vertical Gearnut, Six-Way Seat	
Adjuster - "B-C & E" Body Full Width .	15-20
Fruit, Fruit Stains, Liquor and Wine -	
Stain Removal . . . . .	10-4

## G

Gas Tank Filler Door Hinge Lubrication . .	2-7
Gearnut Assembly (Horizontal), Two-Way	
Seat Adjuster - "C" Body Full Width . .	15-14

Subject	Page No.
Gearnut (Front Vertical), Six-Way Seat	
Adjuster - "B-C & E" Body Full Width .	15-20
Gearnut (Vertical), Four-Way Seat	
Adjuster - "A" Body Full Width . . . . .	15-15
Gearnut (Vertical), Four-Way Seat	
Adjuster - Buick "B-C & E" Body	
Full Width . . . . .	15-18
Genuine Leather and Coated Fabrics,	
Cleaning . . . . .	10-3
Glass, Adhesive Caulked - All Styles . . .	4-1
Glass Run Channel, Front Door Window -	
"A and X" Closed Styles . . . . .	6-77
Glass Run Channel, Front Door Window -	
"B" Closed Styles . . . . .	6-77
Glass Run Channels, Lower -	
Single Acting Tail Gate . . . . .	9-34
Glass Run Channel, Rear Door Window -	
All "A & X" Closed Styles . . . . .	6-97
Glass Run Channel, Rear Door Window -	
All "B" Closed Styles . . . . .	6-98
Glass Run Channel, Rear -	
Front Door Window - "Z" Styles . . .	6-77
Glass Run Channel Sealing Strip	
Assemblies, Front and Rear Door . . . .	6-4
Glass Run Channels, Upper -	
Single Acting Tail Gate . . . . .	9-37
Glass Run Channel, Upper Dual Acting	
Tail Gate Window . . . . .	9-24
Grease and Oil - Stain Removal . . . . .	10-4
Guide Tube, Guide Tube Support and	
Guide Roller, Seat Back Head	
Restraint - Standard Full Width Seats	
60-40 Seats and "F" Type Seats . . . . .	15-31
Guides and Cams Lubrication, Door	
Window Regulator - Styles without	
Upper Frames . . . . .	2-4
Guides and Cams Lubrication, Rear	
Quarter Window Regulator . . . . .	2-5
Gutter Weatherstrip, Front Compartment	
Lid - Corvair . . . . .	5-14

## H

Handle, Door Inside . . . . .	14-3
Handle, Door Pull . . . . .	14-1
Handle, Outside - Dual Acting Tail Gate	
Window Regulator (Manual) . . . . .	9-13
Handle, Outside - Front and Rear Doors . .	6-10
Handle, Rear Quarter Window Regulator . .	14-7
Head Restraint Guide Tube, Guide Tube	
Support and Guide Roller, Seat Back -	
Standard Full Width Seats 60-40 Seats	
and "F" Type Seats . . . . .	15-31
Head Restraint Retainer and Lock, Seat	
Back - Standard Full Width Seats,	
60-40 Seats and "F" Type Seats . . .	15-30
Head Restraint, Seat Back - Standard	
Full Width or 60-40 Seat (Drivers or	
Passenger Side) . . . . .	15-30

<b>Subject</b>	<b>Page No.</b>	<b>Subject</b>	<b>Page No.</b>
Headlining - "55-56-65-66" Station Wagon Styles . . . . .	11-3	Ink, Ball Point - Stain Removal . . . . .	10-5
Headlining Assembly, Front . . . . .	11-5	Inner and Outer Strip Assemblies, Single Acting Tail Gate Window . . . . .	9-36
Headlining Assembly, Rear . . . . .	11-5	Inner Panel Access Hole Covers - Dual Acting Tail Gate . . . . .	9-4
Headlining - Cloth and Vinyl Coated (Soft) - All Styles Except "55-56-65-66" Station Wagons . . . . .	11-1	Inner Panel Access Hole Cover - Single Acting Tail Gate . . . . .	9-28
Headlining, One Piece Formed . . . . .	11-6	Inner Panel Cam, Front Door - All Styles Except "A and X-69" Styles . . . . .	6-58
Hinge Assembly, Dual Acting Tail Gate . . . . .	9-9	Inner Panel Cam, Rear Door - All Except "A and X-69" Styles . . . . .	6-88
Hinge Assembly Lubrication, Front Door . . . . .	2-2	Inner Panel Cover - Single Acting Tail Gate . . . . .	9-25
Hinge Assembly Lubrication, Rear Door . . . . .	2-2	Inner Panel Sealing . . . . .	7-1
Hinge Assembly, Luggage Compartment Front and Rear Panel - Two Seat Styles, Rear . . . . .	15-60	Inner Panel Water Deflector - Dual Acting Tail Gate . . . . .	9-3
Hinge Assembly - Single Acting Tail Gate . . . . .	9-29	Inner Panel Water Deflectors, Front and Rear Doors . . . . .	6-4
Hinge, Front Door - All Styles . . . . .	6-54	Inner Panel Water Deflector - Single Acting Tail Gate . . . . .	9-28
Hinge Lubrication, Gas Tank Filler Door . . . . .	2-7	Inner Trim Panel, Rear Quarter - Left Side ("B" Body Station Wagon Styles) . . . . .	14-13
Hinge Lubrication, Instrument Panel Compartment Door . . . . .	2-2	Inoperative Folding Top in Down ("Stacked") Position, Folding Top - Actuator Assembly . . . . .	13-37
Hinge Lubrication, Rear Compartment . . . . .	2-8	Inside Handle, Dual Acting Tail Gate Door Operation - Remote Control Right Side . . . . .	9-15
Hinge Lubrication, Tail Gate (All Station Wagons) . . . . .	2-6	Inside Handle, Remote Control Dual Acting Tail Gate Operation (Center) . . . . .	9-14
Hinge Mechanism Lubrication, Folding Top . . . . .	2-7	Inside Handles, Door . . . . .	14-3
Hinge and Striker Assembly, Upper - Dual Acting Tail Gate . . . . .	9-21	Inside Locking Rod, Front Door - Coupe Styles . . . . .	6-54
Hinge and Torque Rod Lubrication, Front Compartment Lid . . . . .	2-1	Instrument Panel Compartment Door - Buick "A & E" Styles . . . . .	5-9
Hinges, Front Door - All Styles . . . . .	6-53	Instrument Panel Compartment Door Hinge Lubrication . . . . .	2-2
Hinges, Rear Door - All Styles . . . . .	6-80	Instrument Panel Compartment Door Lock Cylinder and Lock - Buick "A & E" Styles, All Chevrolet Styles . . . . .	5-9
Horizontal Actuator, Four-Way Seat Adjuster - "A" Body Full Width . . . . .	15-16	Instrument Panel Covers - Chevrolet "A, X & Z" and Pontiac "F" Styles . . . . .	5-10
Horizontal Actuator, Four-Way Seat Adjuster - Buick "B-C & E" Body Full Width . . . . .	15-19	Interior Lamp Chart (Above Belt) . . . . .	16-54
Horizontal Actuator, Six-Way Seat Adjuster - "B-C & E" Body Full Width . . . . .	15-20		
Horizontal or Front Vertical Drive Cables, Six-Way Seat Adjuster - Buick, Oldsmobile and Cadillac 60-40 Seats . . . . .	15-23	<b>J</b>	
Horizontal Gearnut Assembly, Two-Way Seat Adjuster - "C" Body Full Width . . . . .	15-14	Jamb Switch (Electric Option), Single Acting Tail Gate . . . . .	9-34
Horizontal Jackscrew, Two-Way Seat Adjuster - "C" Body Full Width . . . . .	15-15	Jamb Switch Lubrication, Door . . . . .	2-3
Horizontal Seat Circuit, Trouble Shooting - Electrical . . . . .	16-32		
Horizontal and Vertical Drive Cables, Four-Way Seat Adjuster - "A" Body Full Width . . . . .	15-16	<b>L</b>	
Horizontal and Vertical Drive Cables, Four-Way Seat Adjuster - Buick "B-C & E" Body Full Width . . . . .	15-19	Lamp Chart, Interior (Above Belt) . . . . .	16-54
Hydraulic Checking Procedure, Folding Top Hydro-Lectric System . . . . .	13-31	Lamps - Tail and Side Marker . . . . .	16-42
Hydro-Lectric System - All Except "Z" Body . . . . .	13-26	Latch Striker Engine Compartment - Corvair Styles . . . . .	8-7
		Leather and Coated Fabrics, Cleaning . . . . .	10-3
		Left Lock Assembly - Dual Acting Tail Gate . . . . .	9-18
Ice Cream - Stain Removal . . . . .	10-4		

Subject	Page No.	Subject	Page No.
Lid, Front Compartment - Corvair . . . . .	5-11	Lock Assembly, Front Roof Rail Folding Top Adjustment - "A, B & C" Styles . .	13-39
Lid Gutter Weatherstrip, Front Compartment - Corvair . . . . .	5-14	Lock Assembly, Front Roof Rail Folding Top Adjustments - "F" Body . . . . .	13-43
Lid Hinge and Torque Rod Lubrication, Front Compartment . . . . .	2-1	Lock Assembly Front Roof Rail, Folding Top - "Z" Body . . . . .	13-49
Lid Latch Engine Compartment - Corvair Styles . . . . .	8-4	Lock Assembly, Rear Door - All Styles . .	6-86
Lid Lock Assembly, Front Compartment - Corvair . . . . .	5-13	Lock Assembly, Single Acting Tail Gate - Right or Left Side . . . . .	9-35
Lid Lock Cylinder Assembly, Front Compartment - Corvair . . . . .	5-13	Lock Cylinder Assembly, Front Compartment Lid - Corvair . . . . .	5-13
Lid Lock Cylinder Assy Rear Compartment - All Styles . . . . .	8-7	Lock Cylinder Assembly, Front Door - All Styles . . . . .	6-56
Lid Lock Lubrication, Front Compartment	2-1	Lock Cylinder and Lock, Instrument Panel Compartment Door - Buick "A & E" Styles, Chevrolet (All Styles) . . . . .	5-9
Lid Lock Lubrication, Rear Compartment .	2-8	Lock Cylinder, Luggage Compartment - 15-16000 Two Seat Styles Rear . . . . .	15-64
Lid Lock Striker, Front Compartment - Corvair . . . . .	5-13	Lock Electric Release Unit, Rear Compartment Lid - Styles Equipped with Option . . . . .	8-14
Lid Support Engine Compartment - Corvair Styles . . . . .	8-4	Lock, Folding Second Seat Back - "55, 56, 65, 66" Styles . . . . .	15-70
Lid Support Lubrication, Engine Compartment . . . . .	2-8	Lock, Folding Second Seat Back (Full Width or Split Seat) - All "A & B" Styles (Except "A-55, 56, 65, 66" Styles) Rear . . . . .	15-64
Lid Torque Rods, Front Compartment - Corvair . . . . .	5-12	Lock, Folding Second Seat Back (Full Width or Split Seat) - All "A & B" Styles (Except "A-55, 56" Styles with Split Seat Option and "65, 66" Styles . .	15-65
Lift Assembly, Folding Top Actuator Assembly . . . . .	13-37	Lock, Folding Third Seat Back - All "A & B" Body Three Seat Styles . . . . .	15-61
Lift Assembly, (Manual) Folding Top - "A, F & Z" Styles . . . . .	13-37	Lock, Folding Third Seat Back - "65-66" Styles . . . . .	15-72
Lift Cylinder, Folding Top Hydro- Electric System . . . . .	13-33	Lock Fork Bolt Lubrication, Door . . . . .	2-3
Linkage Assembly, Folding Second Seat Back (Full Width Seat Right or Left Side Split Seat - Outer Linkage Only) Rear . . . . .	15-63	Lock Fork Bolt Lubrication, Tail Gate (Right and Left) - Station Wagon Styles with Dual Acting Tail Gate . . . . .	2-5
Linkage Assembly, Folding Second Split Seat Back Inner - Rear Seats . . . . .	15-64	Lock and Lock Cylinder, Instrument Panel Compartment Door - Buick "A & E" Styles, All Chevrolet Styles . . . . .	5-9
Linkage, Folding Second Seat Side Inner - "55, 56, 65, 66" Styles . . . . .	15-69	Lock Lubrication, Front Compartment Lid . . . . .	2-1
Linkage, Folding Second Seat Side Outer - "55, 56, 65, 66" Styles . . . . .	15-69	Lock Lubrication, Rear Compartment Lid . . . . .	2-8
Linkage Lubrication, Folding Seat . . . . .	2-7	Lock Parts and Locking Mechanism Lubrication, Door . . . . .	2-3
Lipstick - Stain Removal . . . . .	10-5	Lock Remote Control Assembly, Dual Acting Tail Gate Operation (Center) . . .	9-15
Liquor, Wine, Fruit and Fruit Stains - Stain Removal . . . . .	10-4	Lock Remote Control Assembly, Front and Rear Door Vacuum . . . . .	6-19
Lock Actuator, Front and Rear Door Vacuum or Electric Solenoid . . . . .	6-17	Lock Remote Control Assembly, Single Acting Tail Gate . . . . .	9-35
Lock Adjustment, Front Roof Rail Folding Top - "A, B & C" Styles . . . . .	13-39	Lock Remote Control and Connecting Rod, Front Door - All Styles . . . . .	6-55
Lock Adjustment, Front Roof Rail Folding Top - "F" Body . . . . .	13-43	Lock Remote Control, Rear Door - All Styles . . . . .	6-86
Lock Adjustment, Front Roof Rail Folding Top - "Z" Body . . . . .	13-49	Lock, Seat Back - "F & Z" Body Standard Bucket Seat . . . . .	15-41
Lock Assembly, Dual Acting Tail Gate - Left . . . . .	9-18		
Lock Assembly - Dual Acting Tail Gate, Lower Right Side . . . . .	9-21		
Lock Assembly, Dual Acting Tail Gate - Upper Right Side . . . . .	9-15		
Lock Assembly, Front Compartment Lid - Corvair . . . . .	5-13		
Lock Assembly, Front Door - All Styles .	6-56		



Subject	Page No.	Subject	Page No.
Lock Selector Valves, Front and Rear Door Vacuum . . . . .	6-17		
Lock Storage Tank, Front and Rear Door Vacuum . . . . .	6-19		
Lock Striker Adjustments, Single Acting Tail Gate . . . . .	9-35		
Lock Striker Assembly, Single Acting Tail Gate - Right or Left . . . . .	9-35		
Lock Striker Engagement, Rear Compartment Lid - All Styles Except Corvair and Cadillac Styles with Mechanical Closing Unit Option . . . . .	8-15		
Lock Striker, Front Compartment Lid - Corvair . . . . .	5-13		
Lock Striker Lubrication, Tail Gate . . . . .	2-5		
Lock Striker, Rear Compartment . . . . .	8-15		
Lock Strikers, Front and Rear Doors - All Styles . . . . .	6-10		
Lock Synchronization Check - Tail Gate . . . . .	9-28		
Lock Trim Assembly or Seat Back Panel Assembly, Folding Third Seat - "65-66" Styles . . . . .	15-71		
Lock Trouble Diagnosis Procedure, Front and Rear Door Vacuum . . . . .	6-20		
Locking Mechanism and Lock Parts Lubrication, Door . . . . .	2-3		
Locking Rod, Front Door Inside - Coupe Styles . . . . .	6-54		
Lower Glass Run Channels, Single Acting Tail Gate . . . . .	9-34		
Lower Lock Assembly, Dual Acting Tail Gate - Right Side . . . . .	9-21		
Lower Run Channels, Dual Acting Tail Gate Window . . . . .	9-14		
Lower Striker and Support Assembly, Dual Acting Tail Gate - Right Side . . . . .	9-21		
Lower Support Assembly, Auxiliary Rear Seat - Cadillac Limousine Styles . . . . .	15-56		
Lower Trim, Rear Quarter - "A-80" Style and All Four-Door Styles Except Station Wagons . . . . .	14-12		
Lower and Upper Trim, Center Pillar ("A & X" Four-Door Closed Styles) . . . . .	14-19		
Lower and Upper Trim, Center Pillar - "B & C" Four-Door Closed Styles . . . . .	14-19		
Luggage Compartment Cover Panel and Filler Panel - "55, 56, 65, 66" Styles . . . . .	15-72		
Luggage Compartment Front and Rear Panel Assembly - Two Seat Styles, Rear Seats . . . . .	15-58		
Luggage Compartment Front and Rear Panel Hinge Assembly - Two Seat Styles, Rear . . . . .	15-60		
Luggage Compartment Lock Cylinder - 15-16000 Two Seat Styles Rear . . . . .	15-64		
Luggage Compartment Rear Panel Assembly - Two Seat Styles, Rear Seats . . . . .	15-60		
		<b>M</b>	
		Male Hinge, Folding Top Adjustment - "Z" Body . . . . .	13-50
		Manual Lift Assembly, Folding Top - "A, F, & Z" Styles . . . . .	13-37
		Manually Operated Bucket Seat Adjuster . . . . .	15-37
		Manually Operated Bucket Seat Assembly . . . . .	15-36
		Manually Operated Seat Adjuster Control Arm Knob . . . . .	15-6
		Mechanical Checking Procedure, Folding Top Hydro-Lectric System . . . . .	13-29
		Mechanical Pull-Down Unit Adjustments, Rear Compartment Lid - All Cadillac Styles . . . . .	8-12
		Mechanical Pull-Down Unit Cable, Rear Compartment - All Cadillac Styles . . . . .	8-11
		Mechanical Pull-Down Unit Hydraulic Cylinder, Rear Compartment Lid - All Cadillac Styles . . . . .	8-12
		Mechanical Pull-Down Unit, Rear Compartment Lid - All Cadillac Styles . . . . .	8-11
		Mirror, Door Outside Remote Control, Front - All Styles Without Door Ventilators . . . . .	6-58
		Mirror Remote Controls and Escutcheon, Door Outside . . . . .	14-3
		Molding and Appliques, Door Trim Panel . . . . .	14-7
		Molding and Appliques, Rear Quarter Trim Panel . . . . .	14-13
		Molding Sealing Operation, Exterior . . . . .	17-4
		Molding Tools and Care, Exterior . . . . .	17-4
		Molding Zinc Anode Clips, Exterior . . . . .	17-5
		Motor Description, Power Windows - Electrical . . . . .	16-3
		Moldings, Exterior - Chevrolet "A" Body . . . . .	17-12
		"B" Body . . . . .	17-23
		"F" Body . . . . .	17-30
		"X" Body . . . . .	17-34
		"Z" Body . . . . .	17-39
		Pontiac "A" Body . . . . .	17-44
		"B" Body . . . . .	17-53
		"F" Body . . . . .	17-59
		Oldsmobile "A" Body . . . . .	17-69
		"B-C" Body . . . . .	17-80
		"E" Body . . . . .	17-86
		Buick "A" Body . . . . .	17-92
		"B-C" Body . . . . .	17-102
		"E" Body . . . . .	17-108
		Cadillac "C" Body . . . . .	17-113
		"D" Body . . . . .	17-118
		"E" Body . . . . .	17-121
		Acadian "X" Body (Canadian) . . . . .	17-124
		Beaumont "A" Body (Canadian) . . . . .	17-128
		Pontiac "B" Body (Canadian) . . . . .	17-134

Subject	Page No.	Subject	Page No.
Motor and Pump Assembly, Folding Top - Hydro-Lectric System . . . . .	13-27	Passenger's Front Bucket Seat Back Stop Cable - Chevrolet "F & Z" Styles with Bucket Seats . . . . .	15-41
Motor and Transmission Drive Belts and Pulleys Motor Assembly, Strato- Full Width or Bucket and Standard Bucket Seats . . . . .	5-39	Pillar Trim, Center ("A, B & C" Four- Door Hardtop Stylez) . . . . .	14-19
Mustard - Stain Removal . . . . .	10-5	Plastic Slides, and Lower or Upper Channel - Six-Way Seat Adjuster - "B-C & E" Body Full Width . . . . .	15-21
<b>N</b>		Plastic Slides, Two-Way Seat Adjuster - "C" Body Full Width . . . . .	15-15
Nausea - Stain Removal . . . . .	10-4	Power Operated Four-Way Bucket Seat Adjuster . . . . .	15-37
Notch Down Seat Back and Strato Seat, Center Arm Rest and Curtain Assembly . . . . .	15-34	Power Operated Four-Way Bucket Seat Adjuster Major Components . . . . .	15-38
<b>O</b>		Power Operated Horizontal Bucket Seat Adjuster . . . . .	15-37
Oil and Grease - Stain Removal . . . . .	10-4	Power Operated Horizontal or Four-Way Bucket Seat Assembly . . . . .	15-36
One Piece Formed Headlining . . . . .	11-6	Power Operated Station Wagon Tail Gate Window - Electrical . . . . .	16-12
Operation of Folding Top, Hydro- Lectric System . . . . .	13-28	Power Seats - Electrical . . . . .	16-31
Operation of Pump Assembly, Folding Top Hydro-Lectric System . . . . .	13-28	Power Window Circuit Checking Procedures - Electrical . . . . .	16-5
Operation of Seat Warmer - Electrical . .	16-56	Power Windows - Electrical . . . . .	16-2
Outer and Inner Strip Assemblies, Single Acting Tail Gate Window . . . . .	9-36	Pressure Relief Valve - "A, B, C, E, F & G" Styles . . . . .	5-8
Outlet Duct, Shroud Side Finishing Panel Air - "Z-67" Styles . . . . .	5-6	Pull Handles, Door . . . . .	14-1
Outside Handle, Dual Acting Tail Gate Window Regulator (Manual) . . . . .	9-13	Pump Assembly Operation, Folding Top Hydro-Lectric System . . . . .	13-28
Outside Handles, Front and Rear Doors . .	6-10	<b>Q</b>	
Outside Handle, Single Acting Tail Gate Window Regulator (Manual or Electric) .	9-34	Quarter Arm Rest, Rear . . . . .	14-7
Outside Mirror Remote Controls and Escutcheon, Door . . . . .	14-3	Quarter Front Trim Panel, Rear - Right or Left Side ("A" Body Station Wagons) .	14-14
<b>P</b>		Quarter Inner Trim Panel, Rear - Left Side ("B" Body Station Wagon Styles) . . . . .	14-13
Panel Assembly, Compartment Floor (at Kick-up) Rear - All Styles . . . . .	15-62	Quarter Lower Trim, Rear - "A-80" Style and All Four-Door Styles Except Station Wagons . . . . .	14-12
Panel Assembly, Folding Third Seat Back - Three Seat Styles Rear . . . . .	15-61	Quarter Rear Trim Panel, Rear - Left Side (All "A" Body Station Wagon Styles) . . . . .	14-16
Panel Assembly, Folding Third Seat and Floor - "65-66" Styles . . . . .	15-70	Quarter Trim Panel Molding and Appliques, Rear . . . . .	14-13
Panel Assembly, Folding Third Seat Lock Trim Assembly or Seat Back - "65-66" Styles . . . . .	15-71	Quarter Trim, Rear . . . . .	14-7
Panel and Filler Panel, Luggage Compartment Cover - "55, 56, 65, 66" Styles . . . . .	15-72	Quarter Trim Assemblies, Rear - Two-Door Styles . . . . .	14-7
Panel, Folding Second Seat Back Panel and Filler - "55, 56, 65, 66" Styles . . .	15-70	Quarter Upper Trim, Rear - Above Belt (All Styles) . . . . .	14-16
Panel and Linkage Assembly, Folding Second Seat Back Trim (Full Width or Split Seat) Rear - All Styles . . . . .	15-63	Quarter Wheelhouse Cover Panel, Rear - Right Side ("B" Body Station Wagon Styles) . . . . .	14-13
Panel Moldings and Appliques, Door Trim . . . . .	14-7	Quarter Window Regulator Cams and Guides Lubrication, Rear . . . . .	2-5
Panel Sealing, Inner . . . . .	7-1	Quarter Window Regulator Handle, Rear .	14-7
Panels, Folding Seats and Floor - "55, 56, 65, 66" Styles . . . . .	15-65		

Subject	Page No.	Subject	Page No.
<b>R</b>			
Rear Compartment Front Panel -		Rear Headlining Assembly . . . . .	11-5
Buick & Olds. "E" Styles . . . . .	8-3	Rear Panel Assembly, Luggage	
Rear Compartment Hinge Lubrication . . .	2-8	Compartment - Two Seat Styles Rear	
Rear Compartment Lid - All Styles		Seats . . . . .	15-60
Except Corvair . . . . .	8-1	Rear Quarter Arm Rest . . . . .	14-7
Rear Compartment Lid Lock Cylinder		Rear Quarter Front Trim Panel - Right	
Assy - All Styles . . . . .	8-7	or Left Side ("A" Body Station	
Rear Compartment Lid Lock Electric		Wagons) . . . . .	14-14
Release Unit - Styles Equipped with		Rear Quarter Inner Trim Panel - Left	
Option . . . . .	8-14	Side ("B" Body Station Wagon Styles) . .	14-13
Rear Compartment Lid Lock Lubrication . .	2-8	Rear Quarter Lower Trim - "A-80"	
Rear Compartment Lid Lock Striker . . . .	8-15	Style and All Four-Door Styles Except	
Rear Compartment Lid Lock Striker		Station Wagons . . . . .	14-12
Engagement - All Styles Except Corvair		Rear Quarter Upper Trim - Above Belt	
and Cadillac Styles with Mechanical		(All Styles) . . . . .	14-16
Closing Unit Option . . . . .	8-15	Rear Quarter Rear Trim Panel - Left	
Rear Compartment Lid Mechanical Pull-		Side (All "A" Body Station Wagon	
Down Unit Adjustments - All Cadillac		Styles) . . . . .	14-16
Styles . . . . .	8-12	Rear Quarter Trim . . . . .	14-7
Rear Compartment Lid Mechanical		Rear Quarter Trim Assemblies -	
Pull-Down Unit - All Cadillac Styles . .	8-11	Two-Door Styles . . . . .	14-7
Rear Compartment Lid Mechanical Pull-		Rear Quarter Trim Panel Molding and	
Down Unit Cable - All Cadillac Styles . .	8-11	Appliques . . . . .	14-13
Rear Compartment Lid Mechanical Pull-		Rear Quarter Wheelhouse Cover Panel -	
Down Unit Hydraulic Cylinder - All		Right Side ("B" Body Station Wagon	
Cadillac Styles . . . . .	8-12	Styles) . . . . .	14-13
Rear Compartment Torque Rod		Rear Quarter Window Regulator Cams and	
Adjustment . . . . .	8-3	Guides Lubrication . . . . .	2-5
Rear Compartment Lid Vacuum Release		Rear Quarter Window Regulator Handle . .	14-7
System - Styles Equipped with Option . .	8-13	Rear Seat Back Assembly - All Styles	
Rear Compartment Weatherstrip -		Except Station Wagons and "F & Z"	
All Styles . . . . .	8-16	Body with Folding Rear Seat Back . . . .	15-51
Rear Door Hinges - All Styles . . . . .	6-80	Rear Seat Back Center Arm Rest and	
Rear Door Hinge Assembly Lubrication . .	2-2	Curtain . . . . .	15-52
Rear Door Window Harness, Power		Rear Seat Back Center Arm Rest	
Windows - Electrical . . . . .	16-3	Hanger Plate and Linkage . . . . .	15-52
Rear Floor To Tail Gate Filler Panel		Rear Seat Belt Bail Type Retractor . . . .	15-74
Assembly Compartment Pan Side		Rear Seat Cushion - All Styles (Except	
Filler Panels - "B" Body Two-Seat		"A-65" Styles) . . . . .	15-50
and Three-Seat Styles . . . . .	15-57	Rear Seats . . . . .	15-50
Rear Floor Filler Panel Rear Seats -		Rear Seats (Folding) and Floor Panels,	
All Styles . . . . .	15-62	Station Wagon - All Except "55, 56,	
Rear Guide, Front Door Window - "A-37,		65, 66" Styles . . . . .	15-56
67 and 87" Styles and "G-57" Styles . .	6-76	Rear Trim Panel, Rear Quarter - Left	
Rear Guide, Front Door Window -		Side (All "A" Body Station Wagon Styles)	14-16
"A-39" Styles . . . . .	6-75	Rear Vertical Drive Cables, Six-Way	
Rear Guide, Front Door Window - "B		Seat Adjuster - Buick, Oldsmobile	
and C" Hardtop and Convertible Styles . .	6-76	and Cadillac 60-40 Seats . . . . .	15-23
Rear Guide, Front Door Window -		Reclining Front Seat Back . . . . .	15-46
"B-36, 46 and 69" Styles . . . . .	6-76	Reclining Seat Back Assembly, Front . .	15-47
Rear Guide, Front Door Window -		Reclining Seat Back Lock Control	
"E" Styles . . . . .	6-77	Assembly - Strato Full Width or	
Rear Guide, Front Door Window -		Bucket Seats . . . . .	15-49
"F" Styles . . . . .	6-77	Reclining Seat Back Lock Control	
Rear Guide, Rear Door Window -		Support - Strato Full Width or	
"A-39" Styles . . . . .	6-97	Bucket Seat . . . . .	15-49
Rear Guide, Rear Door Window - "B-39" &		Reclining Seat Back Lock Striker and	
"C-39, 49 & 69" Styles . . . . .	6-97	Seat Back Lock - Strato Full Width or	
		Bucket Seat . . . . .	15-47
		Reclining Seat Back Positioning Unit - Front	15-47

Subject	Page No.
Regulator Cams and Guides Lubrication, Door Window - Styles without Upper Frames . . . . .	2-4
Regulator Cams and Guides Lubrication, Rear Quarter Window . . . . .	2-5
Regulator and Cams Lubrication, Door Window - On Styles with Door Upper Frames . . . . .	2-3
Regulator, Cams and Sector Gear Lubrication, Tail Gate Window (All Station Wagons . . . . .	2-6
Regulator-Electric, Front Door Window - "A-37, 67 and 87", "G-57" and All "B and C" Styles . . . . .	6-75
Regulator Handle, Rear Quarter Window . .	14-7
Regulator-Manual and Electric, Front Door Window - "A-39" Styles . . . . .	6-74
Regulator-Electric, Front Door Window - "A" Closed Styles . . . . .	6-74
Regulator-Manual, Front Door Window - "A and X" Closed Styles . . . . .	6-74
Regulator-Manual and Electric, Front Door Window - "E" Styles . . . . .	6-75
Regulator-Manual and Electric, Front Door Window - "F" Styles . . . . .	6-75
Regulator-Manual, Front Door Window - "A-37, 67 and 87", "G-57" All "B and C" Styles . . . . .	6-75
Regulator-Manual, Front Door Window - "Z" Styles . . . . .	6-75
Regulator Motor Assembly, Electric - Single Acting Tail Gate Window . . . .	9-33
Regulator Motor Electric, Dual Acting Tail Gate Window . . . . .	9-9
Regulator Outside Handle, Dual Acting Tail Gate Window (Manual) . . . . .	9-13
Regulator Outside Handle, Single Acting Tail Gate Window (Manual or Electric) .	9-34
Relay, Power Windows - Electrical . . .	16-3
Relief Valve, Pressure - "A, B, C, E, F, & G" Styles . . . . .	5-8
Remote Control Assembly, Front and Rear Door Lock Vacuum . . . . .	6-19
Remote Controls and Escutcheon, Door Outside Mirror . . . . .	14-3
Remote Control Inside Handle, Dual Acting Tail Gate Operation (Center) . . . . .	9-14
Remote Control Inside Handle, Dual Acting Tail Gate - Door Operation Right Side . . . . .	9-15
Remote Control Lock Assembly, Dual Acting Tail Gate Operation (Center) . . .	9-15
Remote Control Lock Assembly, Single Acting Tail Gate . . . . .	9-35
Remote Control Lock and Connecting Rod, Front Door - All Styles . . . . .	6-55
Remote Control Lock, Rear Door - All Styles . . . . .	6-86
Remote Control Mirror, Front Door Outside - All Styles Without Door Ventilators . .	6-58

Subject	Page No.
Reservoir Tube, Folding Top Hydro- Lectric System . . . . .	13-28
Rod Locking, Front Door Inside - Coupe Styles . . . . .	6-54
Roof Cover, Fabric (All Styles Except Station Wagons) . . . . .	12-1
Roof Cover, Fabric (Station Wagon Styles) .	12-10
Roof Cover and Folding Top, Fabric - Cleaning . . . . .	10-3
Roof Rail Weatherstrip and Retainer - Front and Rear Doors, Side . . . . .	6-6
Run Channels, Lower - Dual Acting Tail Gate Window . . . . .	9-14
Run Channels, Lower - Single Acting Tail Gate Glass . . . . .	9-34
Run Channel, Window Front - All Closed Styles . . . . .	7-7
Run Channel, Window Rear - All Closed Styles . . . . .	7-3

## S

Sealing Operation, Exterior Molding . . . .	17-4
Sealing Strip, Front and Rear Door Glass . . . . .	6-4
Sealing Strip, Window Rear Vertical Inner - "B-37, 47" "C-47, 57" and "G-57" Styles . . . . .	7-2
Sealing Strip, Window Rear Vertical Outer - "B-47", "C-47, 57" and Pontiac, Olds. and Buick "B-37" Styles . . . . .	7-3
Seat Adjuster Assembly, Front (Manual) Full Width . . . . .	15-8
Seat Adjuster Assembly, Front (Power) Full Width . . . . .	15-12
Seat Adjuster Control Arm Knob, Manually Operated . . . . .	15-6
Seat Adjuster Electric Motor, Four-Way - "A" Body Full Width . . . . .	15-15
Seat Adjuster Electric Motor, Four-Way - Buick "B-C & E" Body Full Width . . . .	15-17
Seat Adjuster Electric Motor, Six-Way - "B-C & E" Body Full Width . . . . .	15-20
Seat Adjuster Electric Motor, Six-Way - Buick, Oldsmobile and Cadillac 60-40 Seats . . . . .	15-22
Seat Adjuster Electric Motor, Two-way - "C" Body Full Width . . . . .	15-14
Seat Adjuster Horizontal Actuator, Four-Way - "A" Body Full Width . . . .	15-16
Seat Adjuster Horizontal Actuator, Four-Way - Buick "B-C & E" Body Full Width . . . . .	15-19
Seat Adjuster Horizontal Actuator, Six-Way - "B-C & E" Body Full Width . . . . .	15-20
Seat Adjuster Horizontal or Front Vertical Drive Cables, Six-Way - Buick, Oldsmobile and Cadillac 60-40 Seats . .	15-23
Seat Adjuster Horizontal Gearnut Assembly, Two-Way - "C" Body Full Width . . . .	15-14

Subject	Page No.	Subject	Page No.
Seat Adjuster Horizontal Jackscrew, Two-Way - "C" Body Full Width . . . . .	15-15	Seat Assembly, Auxiliary (Rear) Cadillac Limousine Styles . . . . .	15-53
Seat Adjuster Horizontal and Vertical Drive Cables, Four-Way - "A" Body Full Width . . . . .	15-16	Seat Assembly, Bucket - Manually Operated . . . . .	15-36
Seat Adjuster Horizontal and Vertical Drive Cables, Four-Way - Buick "B-C & E" Body Full Width . . . . .	15-19	Seat Assembly, Folding Second - "55, 56, 65, 66" Styles . . . . .	15-66
Seat Adjuster Lower or Upper Channel and Plastic Slides, Six-Way - "B-C & E" Body Full Width . . . . .	15-21	Seat Assembly, Front (Manual) Full Width .	15-8
Seat Adjuster Major Components, Four-Way - "A" Body Full Width . . .	15-15	Seat Assembly, Front (Power) Full Width .	15-10
Seat Adjuster Major Components, Four-Way - Buick "B-C & E" Body Full Width . . . . .	15-17	Seat Assembly, Power Operated Hori- zontal or Four-Way Bucket . . . . .	15-36
Seat Adjuster Major Components, Power Operated - Four-Way Bucket . . . . .	15-38	Seat Assembly, Strato Full Width - Front . . . . .	15-36
Seat Adjuster Major Components, Six-Way - "B-C & E" Body Full Width . . . . .	15-20	Seat Back Assembly (Front), All "39" Style Full Width and Buick, Oldsmobile and Cadillac 60-40 Seat with Notch Down Center Arm Rest . . . . .	15-27
Seat Adjuster Major Components, Six-Way - Buick, Oldsmobile and Cadillac 60-40 Seats . . . . .	15-22	Seat Back Assembly (Front), Four-Door - Full Width . . . . .	15-26
Seat Adjuster Major Components, Two- Way - "C" Body Full Width . . . . .	15-14	Seat Back Assembly, Front Reclining . . .	15-47
Seat Adjuster, Manually Operated - Bucket . . . . .	15-37	Seat Back Assembly (Front), Seat Back Locks - "A, B, X & Z" Body Two-Door Styles with Standard Full Width . . . . .	15-28
Seat Adjuster Mechanism Lubrication, Folding . . . . .	2-7	Seat Back Assembly (Front), Seat Back Locks - "C & E" Body Two-Door Styles with Standard Full Width and 60-40 Seat . . . . .	15-28
Seat Adjuster Plastic Slides, Two-Way - "C" Body Full Width . . . . .	15-15	Seat Back Assembly (Front), Two-Door Styles with Standard or Notch Down Seat . . . . .	15-27
Seat Adjuster, Power Operated - Four-Way Bucket . . . . .	15-37	Seat Back Assembly, Rear - All Styles Except Station Wagons and "F & Z" Body with Folding Rear Seat Back . . . . .	15-51
Seat Adjuster, Power Operated-Horizontal Bucket . . . . .	15-37	Seat Back Assembly - Standard Bucket Seat "F & Z" Styles . . . . .	15-41
Seat Adjuster Rear Vertical Drive Cables, Six-Way - Buick, Oldsmobile and Cadillac 60-40 Seats . . . . .	15-23	Seat Back Assembly, Strato Bucket - All Except "F & Z" Body Styles and Strato Reclining Seat Back . . . . .	15-46
Seat Adjuster Spacer Usage . . . . .	15-5	Seat Back Assembly, Strato - Four-Door Style with Non Folding Seat Back . . . . .	15-44
Seat Adjuster Transmission, Four-Way - "A" Body Full Width . . . . .	15-17	Seat Back Assembly, Strato - Full Width - 16639 Style . . . . .	15-43
Seat Adjuster Transmission, Four-Way - Buick "B-C & E" Body Full Width . . . . .	15-19	Seat Back Assembly, Strato - Full Width with Stationary Seat Backs, All Styles Except 16639 Style . . . . .	15-42
Seat Adjuster Transmission, Six-Way - "B-C & E" Body Full Width . . . . .	15-22	Seat Back Center Arm Rest and Curtain, Rear . . . . .	15-52
Seat Adjuster Transmission, Six-Way - Buick, Oldsmobile and Cadillac 60-40 Seats . . . . .	15-25	Seat Back Center Arm Rest Hanger Plate and Linkage, Rear . . . . .	15-52
Seat Adjuster Vertical Gearnut, Four-Way - "A" Body Full Width . . . . .	15-15	Seat Back Electric Actuator Assembly, Strato - Cadillac Two-Door Styles Equipped with Electrically Operated Strato Seat Back Locks . . . . .	15-45
Seat Adjuster Vertical Gearnut, Four-Way - Buick "B-C & E" Body Full Width . . . . .	15-18	Seat Back, Folding Rear - "F" Body Styles . . . . .	15-51
Seat Adjuster Vertical Gearnut, Six-Way - "B-C & E" Body Full Width . . . . .	15-20	Seat Back, Folding Rear - "Z" Body Styles . . . . .	15-52
Seat Adjuster Vertical Jackscrew, Four- Way - "A" Body Full Width . . . . .	15-16	Seat Back Head Restraint Guide Tube, Guide Tube Support and Guide Roller - Standard Full Width Seats, 60-40 Seats and "F" Type Seats . . . . .	15-31
Seat Adjustments, Auxiliary (Rear) - Cadillac Limousine Styles . . . . .	15-54		

Subject	Page No.	Subject	Page No.
Seat Back Head Restraint Retainer and Guide Tube, Strato . . . . .	15-44	Seat Back Panel and Filler Panel, Folding Second - "55, 56, 65, 66" Styles . . . . .	16-70
Seat Back Head Restraint Retainer and Lock - Standard Full Width Seats, 60-40 Seats and "F" Type Seats . . . . .	15-30	Seat Back Panel (Front), Strato - Two-Door Style Equipped with Reclining Front Passenger Seat Back . . . . .	15-44
Seat Back Head Restraint - Standard Full Width or 60-40 Seat (Drivers or Passenger Side) . . . . .	15-30	Seat Back Panel, Strato - Two-Door Styles with Passengers Reclining Seat Back . . . . .	15-44
Seat Back Inner Linkage Assembly, Folding Second Split Rear Seats . . . . .	15-64	Seat Back Positioning Unit, Front Reclining . . . . .	15-47
Seat Back Linkage Assembly, Folding Second (Full Width Seat Right or Left Side Split Seat - Outer Linkage Only) Rear . . . . .	15-63	Seat Back, Reclining Front . . . . .	15-46
Seat Back Linkage, Folding Rear - "Z" Body Styles . . . . .	15-52	Seat Back Trim Assembly, Folding Third - Three Seat Styles Rear . . . . .	15-61
Seat Back Lock Assembly, Strato - Two-Door Full Width and Bucket Seats (Except Styles with Reclining Seat Back) . . . . .	15-45	Seat Back Trim, Panel and Linkage Assembly, Folding Second (Full Width or Split Seat) Rear - All Styles . . . . .	15-63
Seat Back Lock - "F & Z" Body Standard Bucket Seat . . . . .	15-41	Seat Back Trim and Spring Assembly, Folding Second (Full Width or Split Seat) Rear - All Styles . . . . .	15-62
Seat Back Lock Control Assembly, Reclining - Strato Full Width or Bucket Seats . . . . .	15-49	Seat Back Trim and Spring Assembly, Folding Second - "55, 56, 65, 66" Styles . . . . .	15-68
Seat Back Lock Control Support, Reclining - Strato Full Width or Bucket Seat . . . . .	15-49	Seat Belt, Bail Type Retractor - Rear . . . . .	15-74
Seat Back Lock and Electric Actuator Assembly - Cadillac Two-Door Styles with Standard Full Width Seat . . . . .	15-29	Seat Belt Retractor, Deluxe Front - Floor Mount . . . . .	15-73
Seat Back Lock, Folding Rear - "F" Body Styles . . . . .	15-52	Seat Belt Retractor, Standard Front - Floor Mount (includes "X" Body Non-Swivel Retractor) . . . . .	15-73
Seat Back Lock, Folding Rear - "Z" Body Styles . . . . .	15-52	Seat Belt Retractor, Standard Front - (Swivel Type) - "X" Body Coupes . . . . .	15-73
Seat Back Lock, Folding Second - "55, 56, 65, 66" Styles . . . . .	15-70	Seat Belt, Self Locking Front . . . . .	15-73
Seat Back Lock, Folding Third - All "A & B" Body Three Seat Styles . . . . .	15-61	Seat Belts and Shoulder Straps . . . . .	15-75
Seat Back Lock, Folding Third - "65-66" Styles . . . . .	15-72	Seat Belts and Shoulder Straps - General Information . . . . .	15-72
Seat Back Lock, Front Seat Back Assembly - "A, B, X & Z" Body Two-Door Styles with Standard Full Width . . . . .	15-28	Seat Cushion Assembly, Folding Second - "55, 56, 65, 66" Styles . . . . .	15-66
Seat Back Lock, Front Seat Back Assembly - "C & E" Body Two-Door Styles with Standard Full Width and 60-40 Seat . . . . .	15-28	Seat Cushion, Folding Third - Three Seat Style Folding Third Seat Cushion Panel Assembly and Support - Three Seat Style . . . . .	15-60
Seat Back Lock Release, Electric . . . . .	16-58	Seat Cushion, Rear - All Styles (Except "A-65" Styles) . . . . .	15-50
Seat Back Lock Release, Electric Circuit Checking Procedures . . . . .	16-58	Seat Cushion Trim Assembly, Folding Third - "65-66" Styles . . . . .	15-71
Seat Back Lock Striker and Seat Back Lock, Reclining - Strato Full Width or Bucket Seat . . . . .	15-47	Seat, Electric Horizontal . . . . .	16-32
Seat Back - Notch Down and Strato Seat, Center Arm Rest and Curtain Assembly . . . . .	15-34	Seat, Electric Four-Way Tilt . . . . .	16-33
Seat Back Panel Assembly - Cadillac Two or Four Door Styles with Standard Seats . . . . .	15-29	Seat, Electric Six-Way Tilt . . . . .	16-37
Seat Back Panel Assembly, Folding Third - Three Seat Styles Rear . . . . .	15-61	Seat and Floor Panel Assembly, Folding Third - "65-66" Styles . . . . .	15-70
		Seat Front Floor Pan Linkage, Folding Second - "55, 56, 65, 66" Styles . . . . .	15-69
		Seat Linkage Lubrication, Folding . . . . .	2-7
		Seat Lock Trim Assembly or Seat Back Panel Assembly, Folding Third - "65-66" Styles . . . . .	15-71
		Seat, Rear . . . . .	15-50
		Seat Rear Floor Pan Linkage, Folding Second - "55, 56, 65, 66" Styles . . . . .	15-69
		Seat Side Inner Linkage, Folding Second - "55, 56, 65, 66" Styles . . . . .	15-69

Subject	Page No.	Subject	Page No.
Seat Side Outer Linkage, Folding Second -		Side Marker and Tail Lamps . . . . .	16-42
"55, 56, 65, 66" Styles . . . . .	15-69	Side Roof Rail Weatherstrip and Retainer,	
Seat - Strato-Full Width or Bucket and		Front and Rear Door . . . . .	6-6
Standard Bucket . . . . .	15-35	Silencer Assembly, Folding Top -	
Seat Torque Specifications . . . . .	15-6	Cadillac Styles . . . . .	13-7
Seat Trim Buttons - Rear . . . . .	15-56	Single Acting Tail Gate . . . . .	9-25
Seat Warmer Components - Electrical . .	16-56	Six-Way Seat Adjuster Electric Motor -	
Seat Warmers - Electrical . . . . .	16-54	"B-C & E" Full Width . . . . .	15-20
Seats, Power - Electrical . . . . .	16-31	Six-Way Seat Adjuster Electric Motor -	
Second Seat Cushion - (Full Width or		Buick, Oldsmobile and Cadillac 60-40	
Split Seat) Rear Seats - All Styles . . .	15-62	Seats . . . . .	15-22
Sector Gear, Window Regulator and Cam		Six-Way Seat Adjuster Horizontal	
Lubrication, Tail Gate (All Station		Actuator - "B-C & E" Body Full	
Wagon) . . . . .	2-6	Width . . . . .	15-20
Self Locking Front Seat Belt . . . . .	15-73	Six-Way Seat Adjuster Horizontal or	
Service Operations - Tail Lamp . . . . .	16-45	Front Vertical Drive Cables - Buick,	
Servicing Procedures Chart - Tail Gate . .	9-24	Oldsmobile and Cadillac 60-40 Seats .	15-23
Shelf Center Finishing Panel, Compartment		Six-Way Seat Adjuster Lower or Upper	
- Oldsmobile and Buick "E" Styles . .	14-20	Channel and Plastic Slides - "B-C & E"	
Shelf Side and Center Trim Panels,		Body Full Width . . . . .	15-21
Compartment - Cadillac "E" Styles . . .	14-20	Six-Way Seat Adjuster Major Components	
Shelf Side Finishing Panel, Compartment -		- "B-C & E" Body Full Width . . . . .	15-20
Oldsmobile and Buick "E" Styles . . .	14-20	Six-Way Seat Adjuster Major Components	
Shelf Trim Assembly, Compartment -		- Buick, Oldsmobile and Cadillac 60-40	
"F-37" Styles with Folding Rear Seat . .	14-23	Seats . . . . .	15-22
Shelf Trim Assembly, Compartment - All		Six-Way Seat Adjuster Rear Vertical	
Styles Except "E & F" Styles and		Drive Cables - Buick, Oldsmobile and	
"F-37" Styles with Folding Rear Seat . .	14-20	Cadillac 60-40 Seats . . . . .	15-23
Shelf Trim, Compartment . . . . .	14-20	Six-Way Seat Adjuster Transmission -	
Shoe Polish and Dressings - Stain Removal	10-5	"B-C & E" Body Full Width . . . . .	15-22
Shoulder Straps and Seat Belts . . . . .	15-75	Six-Way Seat Adjuster Transmission	
Shroud Center Duct Upper Air Outlet and		- Buick, Oldsmobile and Cadillac	
Door -		60-40 Seats . . . . .	15-25
"B and C" Styles . . . . .	5-4	Six-Way Tilt Seat - Electrical . . . . .	16-37
"A and G" Styles . . . . .	5-4	Six-Way Tilt Seat, Electrical Checking	
"F" Styles . . . . .	5-4	Procedure . . . . .	16-38
Shroud Side Air Duct Outlet and Door		Spare Tire Cover Panel (Station Wagon	
(Buick and Cadillac "E" Styles . . . . .	5-7	Styles) . . . . .	14-14
Shroud Side Air Duct Outlet and Door -		Specified Body Opening Clearance	
Oldsmobile "E" Style . . . . .	5-7	Tolerances, Front and Rear Doors . . .	6-10
Shroud Side Finishing Panel -		Spring Clips, Front and Rear Doors . . .	6-10
"A, G, B, C, X and Z-37" Styles . . .	5-4	Standard Front Seat Belt Retractor -	
Shroud Side Finishing Panel - "F"		Floor Mount (Includes "X" Body Non-	
Styles . . . . .	5-6	Swivel Retractor) . . . . .	15-73
Shroud Side Finishing Panel and Air Duct		Standard Front Seat Belt Retractor	
Outlet - "Z-67" Styles . . . . .	5-6	(Swivel Type) - "X" Body Coupes . . .	15-73
Side Air Duct Outlet and Door, Shroud -		Station Wagon Folding Rear Seats and	
Buick and Cadillac "E" Styles . . . . .	5-7	Floor Panels - All Except "55-56-65-66"	
Side Air Duct Outlet and Door, Shroud -		Styles . . . . .	15-56
Oldsmobile "E" . . . . .	5-7	Strato Bucket Seat Back Assembly - All	
Side and Center Trim Panels, Compartment		Except "F & Z" Body Styles and Strato	
Shelf - Cadillac "E" Styles . . . . .	14-20	Reclining Seat Back . . . . .	15-46
Side Finishing Panel and Air Duct Outlet,		Strato Front Seat Back Panel - Two-Door	
Shroud - "Z-67" Styles . . . . .	5-6	Style Equipped with Reclining Front	
Side Finishing Panel, Shroud -		Passenger Seat Back . . . . .	15-44
"A, G, B, C, X and Z-37" Styles . . . .	5-4	Strato-Full Width or Bucket and	
Side Finishing Panel, Shroud - "F"		Standard Bucket Seats . . . . .	15-35
Styles . . . . .	5-6	Strato-Full Width or Bucket and Standard	
Side Finishing Panels, Compartment Shelf -		Bucket Seats - Adjuster Horizontal	
Oldsmobile and Buick "E" Styles . . .	14-20	Actuator Assembly . . . . .	15-40

Subject	Page No.	Subject	Page No.
Strato-Full Width or Bucket and Standard Bucket Seats - Adjuster Jackscrew . . . . .	15-40	Tail Gate Assembly - Dual Acting . . . . .	9-6
Strato-Full Width or Bucket and Standard Bucket Seats - Adjuster Vertical Gearnut . . . . .	15-40	Tail Gate (Dual Acting) Door Operation, Remote Control Inside Handle (Right Side) . . . . .	9-15
Strato-Full Width or Bucket and Standard Bucket Seats - Disassembly and Assembly of Transmission . . . . .	15-39	Tail Gate (Dual Acting) Drain Hole Sealing Strips . . . . .	9-21
Strato-Full Width or Bucket and Standard Bucket Seat - Motor and Transmission Drive Belts and Pulleys Motor Assembly . . . . .	5-39	Tail Gate (Dual Acting) Hinge Assembly . . . . .	9-9
Strato-Full Width or Bucket and Standard Bucket Seats - Torque Tube Assembly . . . . .	15-40	Tail Gate (Dual Acting) Inner Panel, Access Hole Cover . . . . .	9-4
Strato Full Width Front Seat Assembly . . . . .	15-36	Tail Gate (Dual Acting) Left Lock Assembly . . . . .	9-18
Strato Seat Back Assembly - Full Width 16639 Style . . . . .	15-43	Tail Gate (Dual Acting) Lower Lock Assembly - Right Side . . . . .	9-21
Strato Seat Back Assembly - Full Width Seat with Stationary Seat Backs, All Styles Except 16639 Style . . . . .	15-42	Tail Gate (Dual Acting) Lower Striker and Support Assembly - Right Side . . . . .	9-21
Strato Seat Back Electric Actuator Assembly - Cadillac Two-Door Styles Equipped with Electrically operated . . . . .	15-45	Tail Gate (Dual Acting) Operation (Center) - Remote Control Inside Handle . . . . .	9-14
Strato Seat Back Locks . . . . .	15-45	Tail Gate (Dual Acting) Remote Control Lock Assembly (Center) . . . . .	9-15
Strato Seat Back Head Restraint Retainer and Guide Tube . . . . .	15-44	Tail Gate (Dual Acting) Safety Switch . . . . .	9-11
Strato Seat Back Lock Assembly - Two-Door Full Width and Bucket Seats (Except Styles with Reclining Seat Back) . . . . .	15-45	Tail Gate (Dual Acting) Torque Rods . . . . .	9-6
Strato Seat Back Panel - Four-Door Style with Non Folding Seat Back . . . . .	15-44	Tail Gate (Dual Acting) Upper Hinge and Striker Assembly . . . . .	9-21
Strato Seat Back Panel - Two-Door Styles with Passengers Reclining Seat Back . . . . .	15-44	Tail Gate (Dual Acting) Upper Lock Assembly - Right Side . . . . .	9-15
Striker, Front Compartment Lid Lock - Corvair . . . . .	5-13	Tail Gate (Dual Acting) Weatherstrips . . . . .	9-21
Striker Lubrication, Tail Gate Lock . . . . .	2-5	Tail Gate (Dual Acting) Window Assembly - Manual or Electric . . . . .	9-5
Striker Adjustments, Single Acting Tail Gate Lock . . . . .	9-35	Tail Gate (Dual Acting) Window Regulator - Manual or Electric . . . . .	9-9
Striker Assembly, Single Acting Tail Gate Lock - Right or Left . . . . .	9-35	Tail Gate Fabric Cover . . . . .	12-13
Striker and Support Assembly, Lower Right Side - Dual Acting Tail Gate . . . . .	9-21	Tail Gate Hinge Lubrication (All Station Wagons) . . . . .	2-6
Strikers, Front and Rear Door Lock - All Styles . . . . .	6-10	Tail Gate Lock Fork Bolt Lubrication (Right and Left) - Station Wagon Styles with Dual Acting Tail Gate . . . . .	2-5
Strip Assemblies, Window Inner and Outer - All Styles . . . . .	7-7	Tail Gate Lock Striker Lubrication . . . . .	2-5
Support Assemblies - Single Acting Tail Gate . . . . .	9-30	Tail Gate Torque Rod Lubrication (All Station Wagons) . . . . .	2-6
Support Lubrication, Engine Compartment Lid . . . . .	2-8	Tail Gate Upper Glass Run Channels - Single Acting . . . . .	9-37
Switch, Jamb (Electric Option) - Single Acting Tail Gate . . . . .	9-34	Tail Gate Weatherstrip - Single Acting . . . . .	9-37
Switch Lubrication, Door Jamb . . . . .	2-3	Tail Gate Window Circuit - Electrical . . . . .	16-12
		Tail Gate Window (Dual Acting) Upper Glass Run Channel . . . . .	9-24
		Tail Gate Window, Power Operated - Electrical . . . . .	16-12
		Tail Gate Window Regulator, Cams and Sector Gear Lubrication (All Station Wagons) . . . . .	2-6
		Tail Gate - Single Acting . . . . .	9-25
		Tail Gate Assembly - Single Acting . . . . .	9-30
		Tail Gate Drain Hole Sealing Strips - Single Acting . . . . .	9-37
		Tail Gate Hinge Assembly - Single Acting . . . . .	9-29
		Tail Gate Inner Panel Access Hole Cover - Single Acting . . . . .	9-28
		Tail Gate Inner Panel Cover - Single Acting . . . . .	9-25
Tail Gate, Dual Acting . . . . .	9-1		
Tail Gate Adjustments - Dual Acting . . . . .	9-9		



Subject	Page No.	Subject	Page No.
Tail Gate Inner Panel Water Deflector - Single Acting . . . . .	9-28	Torque Rod Lubrication, Tail Gate (All Station Wagons) . . . . .	2-6
Tail Gate (Single Acting) Jamb Switch - Electric Option . . . . .	9-34	Torque Rod - Single Acting Tail Gate . . .	9-36
Tail Gate Lock Assembly, Single Acting - Right or Left Side . . . . .	9-35	Torque Rods, Front Compartment Lids - Corvair . . . . .	5-12
Tail Gate Lock Remote Control Assembly - Single Acting . . . . .	9-35	Torque Specifications, Seat . . . . .	15-6
Tail Gate Lock Striker Adjustments - Single Acting . . . . .	9-35	Torque Tube Assembly - Strato-Full Width or Bucket and Standard Bucket Seats . . . . .	15-40
Tail Gate Lock Striker Assembly, Single Acting - Right or Left . . . . .	9-35	Transmission Assembly and Horizontal and Vertical Drive Cables - Strato Full Width or Bucket and Standard Bucket Seats . . . . .	15-39
Tail Gate Lower Glass Run Channel - Single Acting . . . . .	9-34	Transmission, Disassembly and Assembly - Strato-Full Width or Bucket and Standard Bucket Seats . . . . .	15-39
Tail Gate Support Assemblies - Single Acting . . . . .	9-30	Transmission, Four-Way Seat Adjuster - "A" Body Full Width . . . . .	15-17
Tail Gate Torque Rod - Single Acting . . .	9-36	Transmission, Four-Way Seat Adjuster - Buick "B-C & E" Body Full Width . . .	15-19
Tail Gate Window Assembly - Single Acting (Manual or Electric) . . . . .	9-32	Transmission, Six-Way Seat Adjuster - "B-C & E" Body Full Width . . . . .	15-22
Tail Gate Window Electric Regulator Motor Assembly - Single Acting . . . . .	9-33	Transmission, Six-Way Seat Adjuster - Buick, Oldsmobile and Cadillac 60-40 Seats . . . . .	15-25
Tail Gate Window Inner and Outer Strip Assemblies - Single Acting . . . . .	9-36	Trim Assembly, Compartment Shelf - "F-37" Styles with Folding Rear Seat . .	14-23
Tail Gate Window Regulator - Single Acting (Manual or Electric) . . . . .	9-32	Trim Assembly, Folding Third Seat Back - Three Seat Styles Rear . . . . .	15-61
Tail Gate Window Regulator Outside Handle - Single Acting (Manual or Electric) . . . . .	9-34	Trim Assemblies, Door . . . . .	14-4
Tail Lamp Bulb Usage Chart . . . . .	16-43	Trim Assemblies, Folding Top - Complete	13-1
Tail Lamp Service Operations		Trim Assemblies, Rear Quarter - Two-Door Styles . . . . .	14-7
Chevrolet, Acadian Beaumont . . . . .	16-45	Trim Buttons, Rear Seat . . . . .	15-56
Pontiac . . . . .	16-47	Trim Cover Panel, Wheelhouse - Right Side (All "A" Body Station Wagon Styles) . . . . .	14-15
Oldsmobile . . . . .	16-49	Trim, Door . . . . .	14-1
Buick . . . . .	16-51	Trim Panel Molding and Appliques, Rear Quarter . . . . .	14-13
Cadillac . . . . .	16-53	Trim Panel Moldings and Appliques, Door . . . . .	14-7
Tail Lamps and Side Marker Lamps . . . .	16-42	Trim Panel, Rear Quarter Front - Right or Left Side ("A" Body Station Wagons) .	14-14
Tar - Stain Removal . . . . .	10-5	Trim Panel, Rear Quarter Inner - Left Side ("B" Body Station Wagon Styles) . .	14-13
Tire Cover Panel, Spare (Station Wagon Styles) . . . . .	14-14	Trim Panel, Rear Quarter Rear - Left Side (All "A" Body Station Wagon Styles) . . . . .	14-16
Tools and Care, Exterior Molding . . . .	17-4	Trim Panels, Compartment Shelf Side and Center - Cadillac "E" Styles . . . .	14-20
Top Control Link, Folding Top Adjustments - "A, B & C" Styles . . . . .	13-39	Trim, Rear Quarter . . . . .	14-7
Top Control Link, Folding top Adjustment - "F" Body . . . . .	13-44	Trim and Spring Assembly, Folding Second Seat Back (Full Width or Split Seat) Rear - All Styles . . . . .	15-62
Top Control Link, Folding Top Adjustment - "Z" Body . . . . .	13-49	Trim and Spring Assembly, Folding Second Seat Back - "55, 56, 65, 66" Styles . . . . .	15-68
Top Cover, Folding and Back Curtain Installation - Complete . . . . .	13-9	Two-Way Seat Adjuster Plastic Slides - "C" Body Full Width . . . . .	15-15
Top Cover, Folding - Less Back Curtain . .	13-13		
Top and Fabric Roof Cover, Folding - Cleaning . . . . .	10-3		
Top Hinge Mechanism Lubrication, Folding . . . . .	2-7		
Top Lift Assembly, Folding Top Actuator Assembly . . . . .	13-37		
Torque Rod Adjustment - Rear Compartment . . . . .	8-3		
Torque Rod, Dual Acting Tail Gate . . . .	9-6		
Torque Rod and Lid Hinge Lubrication, Front Compartment . . . . .	2-1		

Subject	Page No.
Trouble Shooting Chart, Folding Top Adjustments - "A, B & C" Styles . . . .	13-42
Trouble Shooting Chart, Folding Top Adjustments - "F" Body . . . . .	13-50
Trouble Shooting Chart, Folding Top - "Z" Body . . . . .	13-50
Trouble Shooting of Horizontal Seat Circuit - Electrical . . . . .	16-32
Two-Way Seat Adjuster Electric Motor - "C" Body Full Width . . . . .	15-14
Two-Way Seat Adjuster Horizontal Jackscrew - "C" Body Full Width . . . .	15-15
Two-Way Seat Adjuster Major Components - "C" Body Full Width . . . . .	15-14

## U

Underbody Alignment	
Corvair "Z" Styles . . . . .	3-1
Camaro and Firebird "F" Bodies . . . .	3-5
Chevy Nova and Acadian "X" Bodies . . .	3-5
Upper Air Outlet and Door, Shroud	
Center Duct -	
"B and C" Styles . . . . .	5-4
"A and G" Styles . . . . .	5-4
"F" Styles . . . . .	5-4
Upper Glass Run Channel - Single Acting Tail Gate . . . . .	9-37
Upper Hinge and Striker Assembly - Dual Acting Tail Gate . . . . .	9-21
Upper Lock Assembly, Dual Acting Tail Gate - Right Side . . . . .	9-15
Upper and Lower Trim, Center Pillar - "B & C" Four-Door Closed Styles . . . .	14-19
Upper and Lower Trim, Center Pillar ("A & X" Four-Door Closed Styles) . . .	14-19
Upper Trim, Rear Quarter - Above Belt (All Styles) . . . . .	14-16
Urine - Stain Removal . . . . .	10-5

## V

Vacuum Door Lock System, Front and Rear Doors . . . . .	6-16
Vacuum Lock Actuator or Electric Solenoid, Front and Rear Doors . . . .	6-17
Vacuum Lock Remote Control Assembly, Front and Rear Door . . . . .	6-19
Vacuum Lock Selector Valves, Front and Rear Doors . . . . .	6-17
Vacuum Lock Storage Tank, Front and Rear Door . . . . .	6-19
Vacuum Lock Trouble Diagnosis Procedure, Front and Rear Door . . . . .	6-20
Vacuum Release System, Rear Compart- ment Lid - Styles Equipped with Option .	8-13
Valve, Fluid Control - Folding Top Hydro-Lectric System . . . . .	13-29
Valve, Pressure Relief - "A, B, C, E, F, & G" Styles . . . . .	5-8

Subject	Page No.
Ventilator Assembly, Front Door - "A-39" Styles . . . . .	6-59
Ventilator Assembly, Front Door - "A" Closed Styles . . . . .	6-58
Ventilator Assembly, Front Door - "X" Styles . . . . .	6-61
Ventilator Assembly, Front Door - "Z" Styles . . . . .	6-61
Ventilator Assembly Weatherstrip, Front Door - "Z" Styles . . . . .	6-62
Ventilator Disassembly and Assembly, Front Door - "A" Closed Styles . . . .	6-59
Ventilator Disassembly and Assembly, Front Door - "A-39" Styles . . . . .	6-60
Ventilator Regulator, Front Door - "A" Styles . . . . .	6-58
Ventilation System Components - Non-Air Conditioning . . . . .	5-1
Vertical (Rear) Drive Cables, Six-Way Seat Adjuster - Buick, Oldsmobile and Cadillac 60-40 Seats . . . . .	15-23
Vertical Gearnut, Four-Way Seat Adjuster - "A" Body Full Width . . . . .	15-15
Vertical Gearnut, Four-Way Seat Adjuster - Buick "B-C & E" Body Full Width . . . . .	15-18
Vertical Gearnut (Front), Six-Way Seat Adjuster "B-C & E" Body Full Width . .	15-20
Vertical and Horizontal Drive Cables, Four-Way Seat Adjuster - "A" Body Full Width . . . . .	15-16
Vertical and Horizontal Drive Cables, Four-Way Seat Adjuster - Buick "B-C & E" Full Width . . . . .	15-19
Vertical Jackscrew, Four-Way Seat Adjuster - "A" Body Full Width . . . .	15-16

## W

Water Deflectors, Front and Rear Door Inner Panel . . . . .	6-4
Water Deflector, Inner Panel - Dual Acting Tail Gate . . . . .	9-3
Water Deflector, Single Acting Tail Gate Inner Panel . . . . .	9-28
Weatherstrips - Dual Acting Tail Gate . . .	9-21
Weatherstrip, Front Compartment Lid Gutter - Corvair . . . . .	5-14
Weatherstrip, Front Door Ventilator - "Z" Styles . . . . .	6-62
Weatherstrips, Front and Rear Doors . . .	6-1
Weatherstrips, Front and Rear Door Center Pillar - "C-69" Styles . . . . .	6-9
Weatherstrip, Rear Compartment - All Styles . . . . .	8-16
Weatherstrip and Retainer, Front and Rear Door Side Roof Rail . . . . .	6-6
Weatherstrip - Single Acting Tail Gate . .	9-37
Wedge Plate, Adjustment of Front Roof Rail - Folding Top - "Z" Body . . . . .	13-48

Subject	Page No.	Subject	Page No.
Wedge Plates, Front Door - "67" Styles . . . . .	6-79	Window Assembly, Rear Door - "X-69" Styles . . . . .	6-96
Wheelhouse Cover Panel, Rear Quarter - Right Side ("B" Body Station Wagon Styles) . . . . .	14-13	Window Assembly, Single Acting Tail Gate (Manual or Electric) . . . . .	9-32
Wheelhouse Trim Cover Panel - Right Side (All "A" Body Station Wagon Styles) . . . . .	14-15	Window Electric Regulator Motor Assembly - Dual Acting Tail Gate . . . .	9-9
Wine, Liquor, Fruit and Fruit Stains - Stain Removal . . . . .	10-4	Window Electric Regulator Motor Assembly - Single Acting Tail Gate . . .	9-33
Window Adjustments, Rear Door "A-39" Styles . . . . .	6-90	Window Front Guide and Bracket Assembly, Rear Door - "A-39" Styles . . . . .	6-97
Window Adjustments, Rear Door - "A" Closed Styles . . . . .	6-90	Window Front Guide Assembly - "Z-37 & 67" and "E-87" Styles . . . .	7-33
Window Adjustments, Rear Door - "B-39" and "C-39, 49 & 69" Styles . . .	6-94	Window Front Guide, Front Door - "A-37, 67 and 87" Styles and "G-57" Styles . . . . .	6-76
Window Adjustments, Rear Door - "B" Closed Styles . . . . .	6-93	Window Front Guide, Front Door - "B and C" Hardtop & Convertible Styles . . . . .	6-76
Window Assembly - "A-27 & 77", "B-11" and "X-27" Styles . . . . .	7-3	Window Front Guide, Front Door - "E" Styles . . . . .	6-77
Window Assembly - "A-37, 87 & 67" and "G-57" Styles . . . . .	7-7	Window Front Guide, Front Door - "F" Styles . . . . .	6-77
Window Assembly - "B & C-37, 47, 57 & 67" Styles . . . . .	7-14	Window Front Guide, Rear Door - "B-39 and C-39, 49 & 69" Styles . . . .	6-97
Window Assembly - "E-47" Styles . . . .	7-19	Window Front Run Channel - All Closed Styles . . . . .	7-7
Window Assembly - "E-87" Styles . . . .	7-17	Window Glass Run Channel, Front Door - "A and X" Closed Styles . . . . .	6-77
Window Assembly - "F-37 and 67" Styles . . . . .	7-21	Window Glass Run Channel, Front Door - "B" Closed Styles . . . . .	6-77
Window Assembly - "Z-37 & 67" Styles . .	7-21	Window Glass Run Channel, Rear Door - All "A & X" Closed Styles . . . . .	6-97
Window Assembly, Dual Acting Tail Gate - Manual or Electric . . . . .	9-5	Window Glass Run Channel, Rear Door - All "B" Closed Styles . . . . .	6-98
Window Assembly, Front Door - "A-37, 67 and 87" Styles and "G-57" Styles . . . . .	6-64	Window Guide Assembly - All "F" Styles .	7-33
Window Assembly, Front Door - "A-39" Styles . . . . .	6-62	Window Guide Assembly - "A, G, B & C" Hardtop and Convertibles . . . . .	7-33
Window Assembly, Front Door - "A and X" Closed Styles . . . . .	6-62	Window Harness, Power Windows Front Door - Electrical . . . . .	16-2
Window Assembly, Front Door - "B and C-37, 47, 57 and 67" Styles . . . . .	6-67	Window Harness, Power Windows Rear Door - Electrical . . . . .	16-3
Window Assembly, Front Door - "B-11" Styles . . . . .	6-66	Window Inner and Outer Strip Assemblies - All Styles . . . . .	7-7
Window Assembly, Front Door - "B-36, 46 and 69" Styles . . . . .	6-66	Window Inner and Outer Strip Assemblies - Single Acting Tail Gate . . . . .	9-36
Window Assembly, Front Door - "B-39" and "C-39, 49 and 69" Styles . . . . .	6-68	Window Lower Run Channels - Dual Acting Tail Gate . . . . .	9-14
Window Assembly, Front Door - "E" Styles . . . . .	6-70	Window Motor - "A-27, 37, 77 & 87" and "G-57" and "F-37, 67" Styles . . .	7-29
Window Assembly, Front Door - "F" Styles . . . . .	6-71	Windows, Power - Electrical . . . . .	16-2
Window Assembly, Front Door - "Z" Styles . . . . .	6-72	Window Rear Glass Run Channel, Front Door - "Z" Styles . . . . .	6-77
Window Assembly, Rear Door - "A-39" Styles . . . . .	6-90	Window Rear Guide Assembly - "Z-37 & 67" and "E-87" Styles . . . .	7-34
Window Assembly, Rear Door - "A" Closed Styles . . . . .	6-88	Window Rear Guide, Front Door - "A-39" Styles . . . . .	6-75
Window Assembly, Rear Door - "B-39" and "C-39, 49 & 69" Styles . . .	6-94	Window Rear Guide, Front Door - "A-37, 67 and 87" Styles and "G-57" Styles . .	6-76
Window Assembly, Rear Door - "B" Closed Styles . . . . .	6-93		

Subject	Page No.	Subject	Page No.
Window Rear Guide, Front Door - "B and C" Hardtop and Convertible Styles . . . . .	6-76	Window Regulator (Manual or Electric) - "A, E, F, G & Z" Hardtop and Convertible Styles . . . . .	7-28
Window Rear Guide, Front Door - "B-36, 46 and 69" Styles . . . . .	6-76	Window Regulator (Manual or Electric) - "A-27 & 77", "B-11" and "X-27" Styles . . . . .	7-24
Window Rear Guide, Front Door - "E" Styles . . . . .	6-77	Window Regulator (Manual or Electric) - "B-C" Hardtop and Convertible Styles . . . . .	7-29
Window Rear Guide, Front Door - "F" Styles . . . . .	6-77	Window Regulator-Manual and Electric, Front Door - "E" Styles . . . . .	6-75
Window Rear Guide, Rear Door - "A-39" Styles . . . . .	6-97	Window Regulator-Manual and Electric, Front Door - "F" Styles . . . . .	6-75
Window Rear Guide, Rear Door - "B-39" & "C-39, 49 & 69" Styles . . . .	6-97	Window Regulator-Manual, Front Door - "A and X" Closed Styles . . . . .	6-74
Window Rear Run Channel - All Closed Styles . . . . .	7-3	Window Regulator-Manual, Front Door - "A-37, 67 and 87", "G-57" All "B and C" Styles . . . . .	6-75
Window Rear Vertical Inner Sealing Strip - "B-37, 47", "C-47, 57" and "G-57" Styles . . . . .	7-2	Window Regulator-Electric, Front Door - "A-37, 67 and 87", "G-57" and All "B and C" Styles . . . . .	6-75
Window Rear Vertical Outer Sealing Strip - "B-47", "C-47, 57" and Pontiac, Olds. and Buick "B-37" Styles . . . . .	7-3	Window Regulator-Manual and Electric, Front Door - "A-39" Styles . . . . .	6-74
Window Regulator Cams and Guides Lubrication, Door - Styles without Upper Frames . . . . .	2-4	Window Regulator-Manual, Front Door - "Z" Styles . . . . .	6-75
Window Regulator Cams and Guides Lubrication, Rear Quarter . . . . .	2-5	Window Regulator-Manual, Rear Door - "A-39 & 69" Styles . . . . .	6-96
Window Regulator and Cams Lubrication, Door - On Styles with Door Upper Frames . . . . .	2-3	Window Regulator-Manual, Rear Door - "B and C" Styles . . . . .	6-96
Window Regulator, Cams and Sector Gear Lubrication, Tail Gate (All Station Wagons) . . . . .	2-6	Window Regulator Outside Handle, Dual Acting Tail Gate - Manual . . . . .	9-13
Window Regulator, Dual Acting Tail Gate - Manual or Electric . . . . .	9-9	Window Regulator Outside Handle, Single Acting Tail Gate - Manual or Electric . .	9-34
Window Regulator-Electric, Front Door - "A" Closed Styles . . . . .	6-74	Window Regulator, Rear Door "X-69" Styles . . . . .	6-97
Window Regulator Electric Motor Removal, Front and Rear Door - "E" Styles . . . . .	6-30	Window Regulator, Single Acting Tail Gate - Manual or Electric . . . . .	9-32
Window Regulator Electric Motor Removal, Front and Rear Door - All Styles Except "E" Styles . . . . .	6-24	Window Run Channel - "E-47" Styles . . .	7-34
Window Regulator Electric Motor Removal, Rear Door - All Styles . . . .	6-96	Window Stationary Ventilator Assembly, Rear Door "X-69" Styles . . . . .	6-95
Window Regulator-Electric, Rear Door - "A, B and C" Styles . . . . .	6-96	Window Stationary Ventilator Division Channel Rear Door - " -69" Styles . . .	6-95
Window Regulator Handle, Rear Quarter . .	14-7	Window Upper Glass Run Channel - Dual Acting Tail Gate . . . . .	9-24
		<b>Z</b>	
		Zinc Anode Clips, Exterior Molding . . . .	17-5